



Edition
04/2022

OPERATING INSTRUCTIONS

SIMOTICS SD

Low Voltage Motors

1LE7
SH71 ... 315

www.siemens.com/drives

SIMOTICS SD

Low-Voltage Motors

1LE7 shaft heights 71 ... 315

Operating Instructions

Introduction

1

Safety information

2

Description

3

Preparing for use

4

Installation

5

Electrical connection

6

Commissioning

7

Operation

8

Maintenance

9

Spare parts

10

Disposal

11

Service & support

A

Technical data

B

Quality documents

C

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol. Notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
Indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
Indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
Indicates that minor personal injury can result if proper precautions are not taken.
NOTICE
Indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The products/systems described in this documentation may be operated only by personnel qualified for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks owned by third parties for their own purposes, could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

4.5	Transport and storage	26
4.5.1	Safety instructions for transport	26
4.5.2	Transport	29
4.5.3	Storage	29
4.5.4	Securing the rotor	31
4.5.5	Commissioning after storage	32
4.5.5.1	Insulation resistance and polarization index	32
4.5.5.2	Regreasing rolling bearings after storage periods of up to two years	33
4.5.5.3	Releasing the rotor shipping brace before commissioning	33
4.6	Ensure adequate cooling	34
4.7	Interlock circuit for anti-condensation heating	36
4.8	Noise emission	36
4.9	Voltage and frequency fluctuations during line operation	37
4.10	Rotational speed limit values	37
4.11	System-inherent frequencies	37
4.12	Electromagnetic compatibility	38
4.13	Converter operation	39
4.13.1	Paralleling the converter	39
4.13.2	Converter input voltage	39
4.13.3	Reducing bearing currents during operation with converter (low voltage)	40
4.13.4	Insulated bearings for converter operation	41
4.13.5	Tandem operation	42
5	Installation	43
5.1	Safety instructions for installation	43
5.2	Preparing for installation	44
5.2.1	Requirements for installation	44
5.2.2	Insulation resistance	45
5.2.2.1	Insulation resistance and polarization index	45
5.2.2.2	Checking the insulation resistance	45
5.2.3	Preparing the assembly area	47
5.2.4	Lift the motor to where it will be mounted and position it	47
5.2.5	Motors with type of construction IM B15, IM B9, IM V5 and IM V5	48
5.2.6	Foot mounting	48
5.3	Aligning and fixing the motor	49
5.3.1	Measures for alignment and mounting	49
5.3.2	Flatness of the supporting surfaces for conventional motors	50
5.3.3	Motor frame mounting feet (special design)	50
5.4	Installing the motor	51
5.4.1	Preconditions for smooth, vibration-free operation	51
5.4.2	Aligning the motor to the driven machine and mounting	51
5.4.2.1	Selecting bolts	51
5.4.2.2	Horizontal types of construction with mounting feet	51
5.4.2.3	Horizontal types of construction with flange	52
5.4.2.4	Vertical types of construction with flange	52
5.4.3	Releasing the rotor shipping brace	53
5.4.4	Recommended alignment accuracy	53
5.4.5	Mounting the drive output elements	54

6	Electrical connection	57
6.1	Basic rules	57
6.2	Safety instructions for the electrical connection	58
6.3	Connecting the motor	59
6.3.1	Terminal box	60
6.3.1.1	Circuit diagram inside the terminal box cover	60
6.3.1.2	Direction of rotation	60
6.3.1.3	Terminal marking	61
6.3.1.4	Cable entry	61
6.3.1.5	Versions	61
6.3.1.6	Prestraining connection cables	61
6.3.1.7	Connecting prestraining cables	62
6.3.1.8	Minimum air clearances	62
6.3.2	Cable glands	62
6.3.3	Tightening torque	65
6.4	Connecting the grounding conductor	65
6.5	Connecting a temperature self-heating/condensation heater	66
6.6	Conductor connection	67
6.6.1	Type of conductor connection	68
6.6.2	Connecting aluminum conductors	68
6.7	Connecting converters	69
6.8	Final checks	70
7	Commissioning	71
7.1	Measures before commissioning	71
7.1.1	Checks to be carried out prior to commissioning	72
7.1.2	Mechanical and electrical check	73
7.1.3	Converter operation	74
7.1.4	Insulation resistance and polarization index	74
7.1.5	Testing the coupling of the motor	74
7.1.6	Commissioning a separately driven fan	75
7.1.7	Further documents	76
7.1.8	Setpoint values for monitoring the bearing temperature	76
7.2	Switching on	77
8	Operation	79
8.1	Safety instructions for operation	79
8.1.1	Safety instructions relating to ventilation and cooling	82
8.1.1.1	Safety instructions for forced ventilation (option)	82
8.1.1.2	Safety instructions when operating motors with fan	82
8.1.1.3	Motors with fan for the textile industry	82
8.2	Switching on the motor	83
8.3	Deactivating	83
8.4	Switching on again after an emergency switching-off	83
8.5	Stoppages	84

8.5.1	Avoidance of damage to rolling bearings during trouble-shooting	85
8.5.2	Decommissioning the motor	85
8.5.3	Re-commissioning the motor	85
8.6	Faults	86
8.6.1	Inspections in the event of faults	86
8.6.2	Electrical faults	86
8.6.3	Mechanical faults	87
8.6.4	Rolling bearing faults	87
8.6.5	Faults on the separately driven fan	88
9	Maintenance	89
9.1	Preparation and notes	89
9.2	Inspection and maintenance	90
9.2.1	Safety instructions for inspection and maintenance	90
9.2.2	Inspections in the event of faults	91
9.2.3	First inspection after installation or repair	91
9.2.4	General inspection	92
9.2.5	Assessing the rolling bearings	92
9.2.6	Maintenance intervals	93
9.2.7	Re-greasing	94
9.2.8	Cleaning	95
9.2.9	Cleaning the fan cover of motors for the textile industry	95
9.2.10	Drain condensate	96
9.2.11	Insulation resistance and polarization index	96
9.2.12	Servicing the separately driven fan	97
9.3	Corrective maintenance	98
9.3.1	Rolling bearings	98
9.3.1.1	Bearing bushes	100
9.3.1.2	Installing bearings	100
9.3.2	Mounting dimension "A"	102
9.3.3	Fan	102
9.3.4	Canopy, encoder under the canopy	103
9.3.5	Tightening torques	104
9.3.6	Screw lock washers	104
9.3.7	Links	104
9.3.8	Assembly: Miscellaneous information	104
9.3.9	Optional add-on units	105
9.3.10	O-ring seal	105
9.3.11	Encoder	106
9.3.12	Grounding brush	106
10	Spare parts	107
10.1	Part lists	107
10.2	Exploded drawings	108
11	Disposal	113
11.1	RoHS - restricting the use of certain hazardous substances	113
11.2	Information according to Article 33 of the REACH regulation	114
11.3	Preparing for disassembly	114
11.4	Disassembling the motor	114
11.5	Disposal of components	115

A	Service & support	117
A.1	Siemens Service Center (Kaiwa)	117
A.2	Siemens Industry Online Support	117
A.3	Further documents	118
B	Technical data	119
B.1	Configurator for drive technology	119
B.2	Tightening torques	119
B.2.1	Tightening torques for screw and bolt connections	119
B.2.2	Terminal board and grounding	120
B.2.3	Terminal boxes, end shields, grounding conductors, sheet metal fan covers	120
B.2.4	Tightening torques for electrical connections of monitoring equipment and arm- condensation heating	121
B.2.5	Tightening torques for cable glands	121
B.3	Technical data and drawings	122
B.3.1	Terminal box dimensions	122
B.3.2	Arrangement of the auxiliary terminal box	123
C	Quality documents	125
C.1	Quality documents SIMOTICS in SIOS	125
	Index	127

1.2 My support

mySupport

Extensive assistance and more information can be found under the following link:

My Support Links and Tools

<https://support.industry.siemens.com/my/www/en/documentation/>

You can individually compile your personal library, e.g. for your documentation based on Siemens content, and adapt it for your own motor documentation.

To do so, click "My Documentation".

Note

If you want to use this function, you must register once.

Later, you can log on with your login data.

You can create your own personal library under "mySupport" using the following procedure:

Prerequisite

You have registered for and logged on to "Siemens Industry Online Support", hereinafter referred to as "SIOS".

SIOS: <https://support.industry.siemens.com/online/en/>

Procedure for creating a personal library

1. Open SIOS and log on.
2. Enter the product you are looking for under "Search for product info" and press "Enter".
3. Select the doc. class you want, e.g. "Manual", under "Entry type".
4. Click on your desired manual under the entries.
5. Click on "Add to mySupport documentation".
6. Enter a title.
7. Press "OK".



The selected manual can be found under "mySupport". To find further functions, click on the icon located to the right of the document.

In this way, you can create your own library and quickly access your documentation.

2.3 Qualified personnel

All work at the motor must be carried out by qualified personnel only. For the purpose of this documentation, qualified personnel is taken to mean people who fulfil the following requirements:

- Through appropriate training and experience, they are able to recognise and avoid risks and potential dangers in their particular field of activity.
- They have been instructed to carry out work on the motor by the appropriate person responsible.

2.4 Safe handling

Workplace safety depends on the attentiveness, care, and common sense of the personnel who install, operate, and maintain the motor. In addition to the safety measures cited, as a matter of principle, the use of caution is necessary when you are near the motor. Always pay attention to your safety.

Also observe the following to prevent accidents:

- General safety regulations applicable in the country where the motor is deployed.
- Manufacturer-specific and application-specific regulations.
- Special agreements made with the operator.
- Separate safety instructions supplied with the motor.
- Safety symbols and instructions on the motor and its packaging.

Danger as a result of stationary parts under voltage (live parts)

Live parts represent a hazard. Touch protection against active (live) parts is no longer guaranteed if covers are removed. The minimum clearance and creepage distances may be violated when coming close to live parts. Touching or coming close to them can result in death, serious injury or material damage.

- Ensure that all live parts are reliably covered.
- Switch off and disconnect the motor first if you want to remove covers. Observe the "5 safety rules" (Page 11).

Risk of injury due to rotating parts

Rotating parts are dangerous. Touch protection against rotating parts is no longer guaranteed if covers are removed. Touching rotating parts can result in death, serious injury or material damage.

- Ensure that all rotating parts are reliably covered.
- Switch off and disconnect the motor first if you want to remove covers. Observe the "5 safety rules" (Page 11).
- Only remove covers when the rotating parts have come to a complete standstill.

Risk of burns due to hot surfaces

Individual motor parts can become hot in operation. Burns can result when coming into contact with these parts.

- Never touch motor parts during operation.
- Allow the motor to cool before starting work on the motor.
- Check the temperature of parts before touching them. If required, wear suitable protective equipment.

Health hazard due to chemical substances

Chemical substances required for the setup, operation and maintenance of motors can present a health risk.

- Observe the product information provided by the manufacturer.

Flammable substances hazard

Chemical substances required for the setup, operation and maintenance of motors may be flammable. These substances can ignite if handled incorrectly. They can cause burns and property damage.

- Observe the product information provided by the manufacturer.

Noise emissions

During operation, the motor's noise emission levels can exceed those permitted at the workplace, which can cause hearing damage.

- Ensure that nobody is in the area of increased noise emissions during motor operation.
- Take steps to reduce noise so that the motor can be operated safely within your system. The following measures may help to reduce noise:
 - Covers
 - Noise insulation
 - Hearing protection measures

Prevention of hearing damage

If the permissible sound pressure level is exceeded, hearing damage can occur when operating three-phase motors at their rated power. The permissible sound pressure level is 70 dB (A).

2.5 Electromagnetic fields when operating electrical power engineering installations

Electrical power equipment generate electromagnetic fields during operation. Potentially lethal malfunctions can occur in medical implants, e.g. pacemakers, in the vicinity of electrical power equipment. Data may be lost on magnetic or electronic data carriers.

- Protect the personnel working in the plant by taking appropriate measures, such as erecting identifying markings, safety barriers and warning signs and giving safety talks.
- Observe the nationally applicable health and safety regulations.
- It is forbidden for people with pacemakers to be close to the motor.
- Do not carry any magnetic or electronic data media.


2.6 Electrostatic sensitive devices

Material damage due to electrostatic discharge

Electronic modules contain components that can be destroyed by electrostatic discharge. These components can be damaged or destroyed if they are not handled correctly. To protect equipment against damage, follow the instructions given below.

- Only touch electronic modules if you absolutely have to work on them.
- The body of the person concerned must have been electrostatically discharged and grounded immediately before any electronic modules are touched.
- Electronic Modules should not be brought into contact with electrically insulating materials, such as:
 - Plastic film
 - Foam parts
 - Insulating table supports
 - Clothing made of synthetic fibers
- Always place electrostatic sensitive devices on conductive bases.
- Always pack, store and transport electronic modules or components in conductive packaging, such as:
 - Metallized plastic or metal containers
 - Conductive foam material
 - Domestic aluminum foil

The ESD protective measures required for components that can be destroyed due to electrostatic discharge are shown in the following drawings:



2.7 Electromagnetic compatibility

This motor is designed in accordance with IEC/EN 60034, and when used as specified, it complies with the requirements of European Directive 2014/53/EU regarding Electromagnetic Compatibility.

2.8 Interference compatibility

By selecting suitable signal cables and evaluation units, ensure that the interference immunity of the motor is not diminished.

2.9 Influence on the line power supply through a strongly irregular torque

A strongly irregular torque, for example with the drive of a reciprocating motor, forces a non-linear motor current. The emerging harmonics can have an impermissible influence on the line power supply via the connection lines.

2.10 Interference voltages when operating the converter

When a converter is in operation, the emitted interference varies in strength depending on the converter (manufacturer, type, interference suppression measures undertaken). On motors with integrated sensors (e.g. PTC thermistors), interference voltages caused by the converter may occur on the sensor lead. This can cause faults which can result in eventual or immediate death, serious injury or material damage.

- Comply with the EMC information provided by the manufacturer of the converter. This is how you prevent the limit values stipulated by IEC/EN 61000-6-2 ... IEC/EN 61000-6-4 for the drive system (consisting of the motor and converter) from being exceeded.
- You must put appropriate EMC measures in place.

2.11 Special designs and construction versions

Before carrying out any work on the motor, determine the motor version.

If there are any deviations or uncertainty, contact the manufacturer, specifying the type designation and serial number (see the rating plate), or contact the Service Center.

3.2 Rating plates

Rating plate

The rating plate shows the identification data and the most important technical data. The data on the rating plate and the contractual agreements define the limits of proper usage.

Data on the rating plate



Item	Description	Item	Description
General data		Electrical data	
1	Type of motor	11	Rated data
2	Motor type	12	Rated voltage V
3	Serial number (incl. date of manufacture YY/MM)	13	Winding connections
4	Dimensions	14	Frequency Hz
5	Additional details (optional)	15	Rated power kW
6	Customer data (optional)	16	Rated current A
7	Country of origin	18	Rated factor cosφ
8	Identification number of issuing agency (optional)	19	Rated speed rpm
09	Company logo	20	Efficiency class
10	Covered shafted box	21	Efficiency
11	IP rated		
Mechanical data			
11	Frame size	17	Installation altitude (only if higher than 1000 m)
12	Type of construction	18	Service time
13	Degree of protection	20	Additional data (specifications (optional))
14	Motor weight kg	21	Brake data (optional)
15	Temperature class	24	Feature key arrangements
16	Additional mechanical frame functions		

3.3 Installation

The regulations and standards used as the basis for designing and testing this motor are stamped on the rating plate. The motor design basically complies with the following standards:

Table 3-1 Application-related regulations

Feature	Standard	
Dimensioning and operating behavior	EN IEC 60034-1	IEC 12615, IEC 60034-1
Procedure for determining the losses and the efficiency of rotating electrical motors and inspection	EN IEC 60034-2-1	IEC 12613
Degree of protection	EN IEC 60034-5	IEC 60034-5
Cooling	EN IEC 60034-3	
Type of construction	EN IEC 60034-7	IEC 2253
Dimensions of three-phase foot-mounted induction motors		IEC 1281
Dimensions of three-phase flange-mounted induction motors		IEC 2233
Terminal markings and direction of rotation	EN IEC 60034-8	IEC 60034-8
Starting characteristics of rotating motors	EN IEC 60034-12	IEC 12815
Vibration severity grades	EN IEC 60034-14	IEC 12833
Efficiency classification of three-phase squirrel-cage induction motors	EN IEC 60034-30-1	IEC 12815
IEC standard voltages	IEC 60038	IEC 12160
Code of practice for winding		IEC 3943
Code of practice for installation and operation of induction motors		IEC 909

- For ratings with higher SDFs than the specified values in IEC 60034-12 for NF design, refer to the catalog.

3.3.1 Cooling and ventilation

3.3.1.1 General

The motors of this series have a closed primary (internal) cooling circuit and an open secondary cooling circuit (surface cooling). The surface cooling varies depending on the version.

3.3.1.2 Motors with a fan


Self-ventilation (standard): Cooling method IC 411 according to EN / IEC 60034-6

Located at the MD end of the stator housing is an air intake cowl that guides the external air on its way to the motor. The external air is drawn in through openings in the air intake cowl and flows axially across the outer cooling ribs of the motor frame. The fan wheel for the external flow of cooling air is attached to the motor shaft.

The fan wheels are bidirectional.

Check the cooling effect below rated speed in the case of frequent switching or braking – or if the speed is controlled continuously below the rated speed.


IC411 IC4A1A1



Forced ventilation (optional): Cooling method IC 416 according to EN / IEC 60034-6


Cooling that does not depend on the speed is achieved by means of a unit that is independent of the motor operating state (forced ventilation). This unit is linked to the outside by a fan cover. It has its own main drive with fan impeller which creates the cooling air flow required for cooling the motor.

IC416 IC4A1A6




3.3.1.3 Motors without a fan (optional)

Surface cooling by free convection: Cooling method IC 410 according to EN / IEC 60034-6



Surface cooling by relative movement of cooling air: Cooling method IC 418 according to EN / IEC 60034-6



3.3.2 Bearings

In order to support the motor shaft and maintain its position in the non-moving part of the motor, only two rolling bearings are used. One rolling bearing performs the function of a location bearing, that transfers axial and radial forces from the rotating motor shaft to the non-moving part of the motor. The second rolling bearing is implemented as a floating and support bearing in order to allow thermal expansion inside the motor and transfer radial forces.

The nominal (calculated) useful life of the bearings according to ISO 281 is at least 50,000 hours if the motor is coupled via a direct flexible coupling. However, the achievable useful life of the bearings can be significantly longer in the case of lower forces (e.g. operation with self-aligning couplings).

Rolling bearings with permanent lubrication are maintenance-free.

The motor is equipped with grease-lubricated rolling bearings.

- In the standard version, the bearings of motors up to shaft height 200 are permanently lubricated.
- The bearings of motors from shaft height 225 and above are equipped with a button head grease nipple.

3.3.3 Balancing

As standard, the motor is designed with vibration severity level A. The rotor is dynamically balanced with a half feather key (code >F).

Vibration severity level B can be ordered as option, and stamped on the rating plate.

3.3.4

Types of construction/method of installation

The type of construction of the motor is stated on the rating plate.

Table 3-2 Type of construction

Basic type of construction code	Diagram	Other methods of installation	Diagram
IM 33 (IM 1001)		IM V5 (IM 1011)	
		IM V6 (IM 1031)	
		IM 36 (IM 1051)	
		IM 27 (IM 1081)	
		IM 38 (IM 1021)	
IM 35 (IM 3001)		IM V1 (IM 3011)	
		IM V3 (IM 3031)	
IM 34 (IM 3601)		IM V10 (IM 3611)	
		IM V18 (IM 3621)	
IM 375 (IM 2501)			
IM 304 (IM 2101)			

3.3.5 Degree of protection

The motor has a type of protection as stamped on the rating plate, and can be installed in dusty or humid environments.

3.3.6 Environmental conditions

Limit values for the standard version

Ambient temperature	-20 °C up to +50 °C
Installation altitude	≤ 1000 m
Air with normal oxygen content, usually	21 % (v/v)

The standard motors are not suitable for use in corrosive atmospheres, atmospheres with a high salt content, or outdoor applications.

Limit values for the special versions

If the environmental conditions are different from the details listed here, then the values on the rating plate or in the catalog will apply.

3.3.7 Optional built-on and built-in accessories

Motors can be equipped with the following integrated components/devices:

- Temperature sensor integrated in the stator winding in order to monitor the temperature and protect the stator winding from overheating.
- Anti-condensation heating for motors whose windings are subject to a risk of condensation due to the climatic conditions.

Motors can be equipped with the following mounted components/devices:

- Brake
- Rotary pulse encoder
- Separately driven fan (forced ventilation)
- Measuring nipple for SPM shock pulse measurement for bearing monitoring

Note:

Further documents

Observe all of the other documents provided with this motor.

Supplementary devices:

Depending on the order, various supplementary devices can be installed or mounted. These include sensors for bearing temperature monitoring or winding monitoring, for example.

Description

Self-Insulation

Preparing for use

Good planning and preparation of motor applications are essential in terms of keeping installation simple and avoiding errors, ensuring safe operation, and allowing access to the motor for servicing and corrective maintenance.

This chapter outlines what you need to consider when engineering/configuring your plant in relation to this motor and the preparations you need to make before the motor is delivered.

4.1 Safety-related aspects to consider when configuring the plant

A number of residual risks are associated with the motor. These are described in Chapter "Safety Information (Page 11)" and related sections.

Take appropriate safety precautions (covers, barriers, markings, etc.) to ensure the motor is operated safely within your plant.

4.2 Observing the operating mode

Observe the motor's operating mode. Use a suitable control system to prevent overspeeds, thus protecting the motor from damage.

4.3 Motors without final paint coating

For motors, which are only delivered with primer, you must paint them to comply with the applicable guidelines for the specific application. The primer alone does not provide adequate corrosion protection.

Please contact the Service Center for recommendations relating to the paint finish.

4.4 Delivery

Checking the delivery for completeness

The drive systems are put together on an individual basis. When you take receipt of the delivery, please check immediately whether the items delivered are in accordance with the accompanying documents. Siemens will not accept any claims relating to items missing from the delivery and which are submitted at a later date.

- Report any apparent transport damage to the delivery agent immediately.
- Report any apparent defect/missing components to the appropriate SIEMENS office immediately.

Archive the safety and commissioning notes provided in the scope of delivery as well as the optionally available operating instructions so that these documents are always easily accessible.

The rating plate optionally enclosed as a loose item with the delivery is provided to enable the motor data to be attached on or near the motor or installation.

4.5 Transport and storage

4.5.1 Safety instructions for transport

Observe the following when carrying out any work on the motor:

- Comply with the general safety instructions (Page 11).
- Comply with the applicable national and sector-specific regulations.
- When using the motor within the European Union, comply with the specifications laid down in EN 50110-1 regarding safe operation of electrical equipment.

The information required to correctly attach, lift and transport the motor – such as weight, center of gravity and attachment points – is provided here:

- Motor dimension drawing and the associated explanations of the technical data
- Transport data
- Rating plate and lifting plate, if available
- Shipping parts list
- Packaging

Danger when incorrectly lifting and transporting

Danger of death, serious injury, or substantial material damage caused by tipping or falling transported goods. Comply with the following safety instructions:

- All work must be performed with due caution and care.
- Comply with any notes in the shipping papers.
- Carefully comply with all of the handling information and markings on the packages whenever transporting and putting the equipment into storage according to ISO 780.
- Only use suitable and adequately dimensioned lifting equipment, transport equipment and industrial blocks.

Danger due to incorrect attachment and lifting

- Ensure that suitable lifting equipment is available.
- Only hoist the goods using the designated hoisting points and/or at marked positions. The attachment points are not dimensioned for additional loads.
- Use suitable strap guiding or spreading devices.
- If not specified otherwise in the transport data, always transport the motor in the position associated with its specific type of construction.

Danger due to damaged attachment points

- Carefully check the attachment points provided on the motor, e.g. attachment eyes, lifting lugs or ring bolts for possible damage. Replace any damaged attachment points.
- Before using, carefully ensure that the attachment points are correctly attached.

Danger when incorrectly transporting the motor suspended from cables or ropes

If you transport the motor suspended from cables or ropes, the cables or ropes can break, e.g. as a result of damage. Further, if not adequately attached, the motor can swing. This can result in death, serious injury, or material damage.

- Use additional, suitable lifting equipment for transport and during installation.
- Two cables alone must be able to carry the complete load.
- Prevent the lifting equipment from sliding by appropriately securing it.
- When using 2-cable lifting equipment, ensure that the maximum angle of inclination is $\leq 45^\circ$ according to ISO 3296 (DIN 580).
- Align the eyebolts so that the cables used for lifting are aligned with the planes of the eyebolts.

Danger when incorrectly lifting and transporting

The motor can slide or topple over if it is not correctly lifted or transported. This can result in **death, serious injury or material damage**.

- Use all the lifting eyes on the motor.
- When using the lifting eyes on the motor, do not attach any additional loads or weight. The lifting eyes are only designed for the weight of the motor (itself).
- Any eyes that are screwed in must be tightly fastened.
- Eyebolts must be screwed in right up to their supporting surface.
- Comply with the permissible eyebolt loads.
- When necessary, use suitably dimensioned lifting equipment, for example hoisting slings (DIN 492-1) and webbing load restraints (DIN 195-2).

Danger if the motor falls

The attachment points on the motor are designed for the weight of the motor only. If a machine set is lifted and transported at a single motor, this can fracture the attachment point. The motor or machine set may fall. This can result in **death, serious injury or material damage**.

- Do not lift machine sets by attaching lifting tackle to the individual motors.
- Use only the equipment provided, e.g. the coverings or lugs on the base plates, for transporting machine sets. Note the maximum capacity of the lifting lig.
- Never remain under or in the immediate vicinity of the motor when it is lifted.

**WARNING****Danger to life as a result of a motor falling**

If the lifting gear or load handling attachments were to fail, the motor could fall. This can result in **death, serious injury or material damage**.

- In order to gain easy and safe access to the underside of the motor, place it in a secure and raised position.

Note

When lifting the motors for transport, only lift them in a position that corresponds to their basic construction type.


The type of construction of the motor is stated on the rating plate.

4.5.2 Transport

If any transport locks are in place, remove them before commissioning. Store the transport locks or disable them. Use the transport locks when transporting the motor again or reactivate the transport locks.

The motors are packed in different ways depending on how they are transported and their size. If not otherwise contractually agreed, the packaging corresponds to the packing guidelines according to ISPM (International Standards for Phytosanitary Measures).

Comply with the graphic symbols provided on the packaging. Their meaning is as follows:



4.5.3 Storage

Storing outdoors

NOTICE

Damage to the motor

Damage can occur if incorrectly stored.

Take all precautions to protect the motor under extreme climatic conditions, e.g. salt-laden and/or dusty, high-humid atmospheres.

Choose a dry storage location which is safe from flooding and free from vibration. Repair any damage to the packaging before putting the equipment into storage if this is necessary to ensure proper storage conditions, or order to ensure protection against ground moisture, locate motors, equipment and crates on pallets, wooden beams or foundations. Prevent equipment from sinking into the ground. Do not impede air circulation under the stored items.

Covers or tarpaulins used to protect the equipment against the weather must not come into contact with the surfaces of the equipment. Use wooden spacer elements to ensure that air can circulate freely around the equipment.

Storing indoors

The storage rooms must provide protection against extreme weather conditions. They must be dry, free from dust, frost and vibration and well ventilated.

4.5.3 Inherent and stored

Bare metal surfaces

For transport, the interfaces (shaft ends, flange surfaces, centering edges) should be coated with an anti-corrosion agent which will last for a limited amount of time (ca. months). Apply suitable anti-corrosion measures for longer storage times.

Condensation drain hole

Open any condensation drain fields to drain the condensation depending on the environmental conditions, every six months at the latest.

Storage temperature

Permissible temperature range: -20 °C to +50 °C

Maximum permissible g humidities: 60%

For motors that have a special design regarding the ambient temperature in the operating state or the installation altitude, other conditions could apply regarding the storage temperature. In this case, refer to the motor rating plate for data on the ambient temperature and installation altitude.

Summary

Turn the shaft once every year to avoid bearing brinelling. Prolonged storage periods reduce the useful life of the bearing grease (caution).

Open bearings

- For open bearings, e.g. IE, check the status of the grease when stored for longer than 12 months.
- Replace the grease if it is identified that the grease has lost its lubricating properties or is polluted. The consistency of the grease will change if condensation is allowed to enter.

Chosen Denim

- For closed bearings, replace the CE and HZL bearings after a storage time of 48 months.

NATIVE

551

The motor can be damaged if you use it or store it unprotected outdoors.

- Protect the motor against intensive solar radiation, rain, snow, ice and dust. Use a superstructure or additional cover, for example.
- If required, contact the service centre, or technically coordinate outdoors use.

4.5.4 Securing the rotor

Depending on the version, the motor is fitted with a rotor shipping brace. This protects the bearings against damage due to shock and vibration during transport or storage.

NOTICE

Motor damage due to vibrations

Not using the rotor shipping brace can cause damage to the motor if it is jolted during transport or storage. Material damage can result.

- If the motor is fitted with a rotor shipping brace, this should always be used when transporting the motor. The rotor shipping brace must be attached during the transport.
- Protect the motor against strong radial shocks and vibration when storing, as the rotor shipping brace cannot completely absorb these forces.
- Do not remove the rotor shipping brace until you are ready to push on the output element.
- If the customer already has mounted parts, such as a coupling or belt pulley, the bearings can be damaged during transport. In this case, make sure that the customer uses a rotor shipping brace.
- For motors with a vertical type of construction:
 - Do not remove the rotor shipping brace until the motor is in a vertical position.
 - If a motor has to be transported in a horizontal position, the rotor must be fixed in position before the motor is turned onto its side. Vertical motors can be supplied in the horizontal position from the manufacturing plant.

Alternative rotor bracing

- If you transport the `idiot` after the output element has been pulled on, then you must *ask* for the `idiot` in another way.




Figure 8-9 Asset leveraging at the time

Tinned in the shaft extension	Tightening torque
M16	85 Nm
M20	100 Nm
M24	150 Nm
M30	230 Nm

High-leaving company for better future prospects. Source: survey

- The dip in the shaft extension indicates the rotor weight. This indirectly specifies the required preload force when axially fastening the rotor.

Thread in the shaft extending	Probed
M16	13 mm
M20	20 mm
M24	30 mm
M30	40 mm

Always pack with care for safer road shipping. Inside boxes.

Storing the rotor locking device

Store the rotor locking device in a safe place. It must be reinstalled if the rotor is removed and shipped or further.

4.5.5 Commissioning after storage

4.5.5.1 Insulation resistance and polarization index

Measuring the insulation resistance and polarization index (PI) provides information on the condition of the motor. It is therefore important to check the insulation resistance and the polarization index at the following times:

- Before starting up a motor for the first time
- After an extended period in storage or downtime
- Within the scope of maintenance work

The following information is provided regarding the state of the winding insulation:

- Is the winding head insulation conductively contaminated?
- Has the winding insulation absorbed moisture?

As such, you can determine whether the motor needs commissioning or any necessary measures such as cleaning and/or drying the winding:

- Can the motor be put into operation?
- Must the windings be cleaned or dried?

Detailed information on testing and the limit values can be found here:

Checking the insulation resistance (Page 45)

4.5.5.2 Regreasing rolling bearings after storage periods of up to two years

- For motors with regreasing systems, briefly lubricate both bearings after commissioning with the motor running as a precautionary measure.
- Grease type, grease quantity and relubrication intervals for the regreasing system are stamped on the rating plate attached to the motor.

4.5.5.3 Releasing the rotor shipping brace before commissioning

If one is being used, release the rotor shipping brace before commissioning.

4.6 Ensure adequate cooling

A WARNING

Overheating and failure of the motor

Death, severe injury or material damage can occur if you do not carefully observe the following points:

- Do not obstruct ventilation;
- Prevent the air expelled by neighboring equipment from being immediately sucked in again;
- For vertical types of motor construction with the air intake from above, protect the air intakes from the ingress of foreign bodies and water;
- If the shaft extension is facing upwards, liquid must be prevented from entering by moving along the shaft.

 WARNING











Damage caused by small parts falling in

Material damage and injury can occur if the fan is destroyed and therefore the manufacturer is liable.

- For types of construction with the shaft extension facing downwards, prevent small parts from falling into the fan cover by providing suitable covers.
- Ensure that the cooling air flow is not reduced as a result of covers and that the minimum air clearances are maintained.

For resistors with separately driven fan, install an interlock circuit that prevents the main motor being switched on if the separately driven fan is not operational.

Table 4-1 Air guidance

Incorrect	Correct
	
	
	
	
	

4.7 Interlock circuit for anti-condensation heating

Table 4-2: Minimum dimension "x" for the distance between adjacent modules and the air intake of the motor

Shaft height	x mm
71	15
80 ... 100	20
112	25
130	30
160	40
180 ... 200	50
225 ... 250	100
280 ... 315	110

4.7 Interlock circuit for anti-condensation heating

If the anti-condensation heating is operated while the motor is running, this can increase the temperatures inside the motor.

- Install an interlock circuit that switches off the anti-condensation heating once the main motor is switched on.
- Only switch on the anti-condensation heating after the motor has been switched off.
Comply with the data stamped on the plate of the anti-condensation heating, if available.

4.8 Noise emission

Prevention of hearing damage

If the permissible sound pressure level is exceeded, hearing damage can occur when operating three-phase motors at their rated power. The permissible sound pressure level is 70 dB(A).

4.9 Voltage and frequency fluctuations during line operation

Unless otherwise stated on the rating plate, the permissible voltage/frequency fluctuation is corresponds to Zone B in IEC / EN 5034-1. Permissible fluctuations that go beyond this are indicated on the rating plate – or for some versions, on a supplementary plate.

Operate the motor in continuous operation in Zone A. Prolonged operation in Zone B is not recommended.

- Exceeding the permissible tolerances for voltage and frequency can lead to an impermissibly high temperature rise of the winding. This can result in long-term damage to the winding.
- Limit exceptions of this sort with regard to the values that arise, how often, and for how long they occur.
- Where possible and within a reasonable time take corrective actions such as reducing the power. In this way you can avoid that the service life of the motor is reduced as a result of thermal aging.

4.10 Rotational speed limit values

Danger as a result of resonance within certain speed ranges

At over-critical speeds, motors encounter resonance within certain speed ranges. Such vibrations can reach impermissibly high levels. This can result in death, serious injury or material damage.

- The controller must ensure that those speed ranges are blocked when the converter is in operation. Please note the data on the blocked speed ranges specified in the Electrical Data.
- The blocked speed ranges must be run through rapidly.

Motor damage due to excessively high speeds

Excessive rotational speed can lead to serious damage to the motor. This can result in death, serious injury or material damage.

- Avoid operation above the permissible speed by using the appropriate control function.
- Observe the speeds stamped on the rating plate and in the Specifice Data.

4.11 System-inherent frequencies

Excessively high vibration levels and system resonances can damage the machine set.

- Configure and match the system consisting of the foundation and machine set in such a way that no system resonances can arise and result in the permissible vibration levels being exceeded.
- The vibration values according to DIN ISO 10816-3 must not be exceeded.

4.12 Electromagnetic compatibility

Note

If the torque levels are very unequal (e.g. when a reciprocating compressor is being driven), a non-conjugated motor current will be induced whose harmonics can have an impermissible effect on the supply system and cause impermissible interference emissions as a result.

Note

Converter

- If operated with a frequency converter, the emitted interference varies in strength, depending on the design of the converter (type, interference suppression measures, manufacturer).
- Avoid that the specified limit values stipulated for the drive system (consisting of the motor and converter) are exceeded.
- You must observe the EMC information from the manufacturer of the converter.
- The most effective method of shielding is to conductively connect a shielded motor supply cable to the metal terminal box of the motor (with a metal screw connection) over a large contact area.
- On motors with integrated sensors (e.g. PTC thermistors), disturbance voltages caused by the converter may occur on the sensor cable.

When used in accordance with their intended purpose, and operated on a line supply with characteristics according to EN 50160, the enclosed motors comply with the requirements of the EC Directive regarding electromagnetic compatibility.

Immunity to interference

The motors fulfill the requirements of interference immunity in conformity with EN IEC 61000-6-2. For motors with integrated sensors, e.g. PTC thermistors, the operating company must ensure sufficient interference immunity by selecting a suitable sensor signal cable (possibly with shielding, connected in the same way as the motor feeder cable) and a suitable evaluation unit.

When operating the motors from a converter at speeds higher than the rated speed, carefully comply with the mechanical speed limits (safe operating speed EN IEC 60034-1).

4.13 Converter operation

4.13.1 Parameterizing the converter

- If the design of the motor requires connection to a particular converter type, the rating plate will contain corresponding additional information.
- Correctly parameterize the converter. Parameterizing data can be taken from the motor rating plates.
You can find parameter data here:
 - in the operating instructions for the converter;
 - in the SIMATIC engineering tool;
 - in the SINAMICS Configuration Manual.
- Do not exceed the specified maximum speed limit.
- Set the stop frequency band between 18 Hz and 48 Hz (both inclusive) for S1H S15 two-pole TEE7 motors when operating on VFD.
- Check that the motor is cooled sufficiently for commissioning purposes.

4.13.2 Converter input voltage

The insulation system of SIMOTICS motors always complies with the requirements of stress category B (IEC B – high stress). If voltage peaks higher than those specified according to IEC B can occur, contact the Service Center.

- For a line supply voltage (converter input voltage) up to max. 480 V, and when controlled from a SINAMICS G1/SINAMICS S converter with uncontrolled/controlled infeed: Comply with the guidelines for configuring motor and converter.
- Operation with a converter from another manufacturer: Comply with the permissible voltage peaks according to IEC 60124-12-41 in accordance with stress category B, dependent on the particular line voltage (converter input voltage) and the motor insulation system.

NOTICE

Material damage caused by an excessively high supply voltage

The insulation system will be damaged if the supply voltage is too high for the insulation system. This can completely destroy the motor.

- Comply with the peak voltages as laid down in the guidelines above.

4.13.3 Reducing bearing currents during operation with converter (low voltage)

Taking the following actions will reduce the bearing currents:

- Ensure that the contacts are made over a large area. Solid copper cables are not suitable for high-frequency grounding because of the skin effect.

Equipotential bonding conductors:


Use equipotential bonding conductors:

- between motor and driven machine
- between motor and converter
- between the terminal box and the HF grounding point at the motor enclosure.

Selecting and connecting the cable:

As far as possible, use symmetrically arranged, shielded connection cables. The cable shielding, made up of as many strands as possible, must have good electrical conductivity. Braided shields made of copper or aluminum are very suitable.

- The shield is connected at both ends, at the motor and converter.
- To ensure good discharging of high-frequency currents, provide contacting over a large surface area:
 - as contact established through IGBT at the converter
 - at the motor, for instance with EMC glands at the cable entry.
- If the cable shield is connected as described, then it ensures the specified equipotential bonding between the motor enclosure and converter. A separate HF equipotential bonding conductor is then not necessary.



- If the cable shield is not connected due to special secondary conditions, or not adequately connected, then the specified equipotential bonding is not provided; in this particular case, use a separate HF equipotential bonding conductor:
 - Between the motor enclosure and protective ground rail of the converter.
 - Between motor enclosure and driven machine.
 - Use braided flat copper straps or high-frequency cables with finely-stranded conductor for the separate HF equipotential bonding cable.
 - Ensure that the contacts are made over a large area.

Measures to reduce bearing currents

To specifically reduce bearing currents, you must consider the system as a whole, which comprises the motor, converter, and driven machine. The following measures support you when reducing bearing currents and help to avoid damage:

- In the overall system, set up a properly meshed grounding system with low impedance.
- Use the common-mode filter (damping core) at the converter output.
- Limit the rise in voltage by using output filters. Output filters dampen the harmonic content in the output voltage.
- The operating instructions for the converter are not part of this documentation. Refer to the configuration information for the converter.

NOTICE

Motor within itself does not induce shaft circulating current to cause bearing failure. Any bearing failure with fluting marks is not to be attributed to motor as a cause. Care must be taken while operating motor with converter to ensure the strict adherence to IEC guidelines by considering motor as a part of a complete system (motor + drive + cabling).

4.13.4 Insulated bearings for converter operation

If the motor is controlled from a low-voltage converter, depending on the motor type, an insulated bearing can be fitted at the ABE.

100

Insulated bearing at NCB is a generally recommended practice. Refer to IEC TS 60034-25 to plan effective countermeasures for reducing bearing currents.

An insulated speed encoder can be optionally mounted

Comply with the information provided on the motor plates relating to bearing installation and possible jumps.




Figure 4-2: Nocturnal temperature cycles in a tropical climate

NOTICE

Learning objectives

The bearing insulation must not be bridged. Bearing currents can damage bearings.

- Do not bridge the bearing insulation for subsequent installation work, such as the installation of an automatic lubrication system or a non-insulated vibration sensor.
- Where necessary, contact the Service Center.

If you connect two motors in series in "independent operation", there is an isolated coupling between the motors.




Table 4-1. Subsequent recommendations of the committee.

NOTES

Learning objectives

Leaking currents can flow if the coupling between the motors of the tandem drive is not insulated. This can damage the DE bearings of both motors.

- Use an insulated coupling to couple the motors.
- As an alternative for machine operation with low-voltage converter, insulated bearing at DE can be fitted depending on motor type, but a non-conductive coupling is recommended.

4.13.5 Tandem operation

If you connect two motors in series in "tandem operation", locate a coupling between the motors; this coupling should satisfy the Directive 2014/34/EU or the regulations that apply in the country where the equipment is installed.

Installation

Observe the following when carrying out any work on the motor:

- Comply with the general safety instructions (Page 11).
- Comply with the applicable national and sector-specific regulations.
- When using the motor within the European Union, comply with the specifications laid down in EN 50112-1 regarding safe operation of electrical equipment.

5.1 Safety instructions for installation

Injury and material damage caused by inappropriate fastening material

If screws of an incorrect property class have been selected or if they have been fastened to an incorrect tightening torque, they may break or become loose. This will cause the motor to move, which could damage the bearings. The motor could crash into the motor enclosure and motor parts could be flung out of place. This can result in death, serious injury or material damage.

- Comply with the required property classes for screwed connections.
- Tighten the screwed connections to the specified tightening torques.

Injury and material damage caused by incorrect motor alignment

If the motor has not been properly aligned, this will mean the fastening parts are subjected to disalignment. Screws may become loose or break, the motor will move, motor parts could be flung out of place. This can result in death, serious injury or material damage.

- Carefully align the motor to the driven machine.

Material damage caused by improper handling

Mounting parts such as temperature sensors or speed sensors are attached to the motor and could be ripped off or destroyed as a result of improper handling. This could lead to motor malfunctions, extending even to total loss of the motor.

- Where necessary, use suitable steps when performing installation work on the motor.
- Do not stand on cables or attachments during installation. Do not use attachments as steps.

Loss of conformity with European directives

In the delivery state, the motor corresponds to the requirements of the European directives. Unauthorized changes or modifications to the motor lead to the loss of conformity with European Directives and the loss of the associated warranty.

5.2 Preparing for installation

5.2.1 Requirements for installation

The following requirements must be satisfied prior to starting installation work:

- Staff have access to the operating and installation instructions.
- The motor is unpacked and ready for mounting at the installation location.
- Measure the insulation resistance of the winding before starting any installation work. If the insulation resistance lies below the specified value, take appropriate remedial measures. These remedial measures may necessitate the motor being removed again and transported.

Note

Also note the technical data on the rating plate on the motor endplate.

NOTICE

Damage to the motor

To avoid material damage, before commissioning, check whether the correct direction of rotation of the motor has been set on the customer side, e.g. by decoupling from the driven load.

Damage to mounted parts and components as a result of high temperatures

The motor components get very hot during operation. High temperatures can damage parts mounted by customers, such as cables manufactured out of materials that are not heat resistant.

- Temperature-sensitive parts must not come into contact with or be attached to components mounted on the motor.
- Only use heat-resistant mounting parts. The connecting cables and cable entries must be suitable for the particular application.

Measuring the insulation resistance and polarization index (PI) provides information on the

- Before starting up a motor for the first time

- The following information is provided regarding the state of the pending regulation:

- As such, you can determine whether the motor needs commissioning or any necessary measures such as cleaning and/or drying the winding.

- Detailed information on testing and the limit values can be found under:

5.2.2.1 Checking the Insulation resistance



Minimum Voltage at the terminals

- If any power cables are connected, check to make sure the supply voltage cannot be delivered.

- © 2004 Blackwell Publishing Ltd *Journal of Internal Medicine* 255: 105–114

Measure the insulation resistance

1. Before you begin measuring the insulation resistance, read the operating manual for the insulation resistance meter you are going to use.
2. Make sure that no power cables are connected.
3. Measure the winding temperature and the insulation resistance of the winding in relation to the motor enclosure. The winding temperature should not exceed 50 °C during the measurement. Convert the measured insulation resistances in accordance with the formula to the reference temperature of 50 °C. This thereby ensures that the minimum values specified can be compared.
4. Read out the insulation resistance one minute after applying the measuring voltage.

Conversion to the reference temperature

When measuring with winding temperatures other than 50 °C, convert the measuring value to the reference temperature of 50 °C according to the following equations (from IEC 43-2009).

(1)	R	Insulation resistance measured at 50 °C reference temperature
	$k = R_1 / R_2$	Temperature coefficient according to equation (2)
	R ₂	Measured insulation resistance for measuring/winding temperature T in °C
(2)	50	Reference temperature in °C
	10	Halving/doubling of the insulation resistance with 10 K
	T	Measuring/winding temperature in °C

In this case, doubling or halving the insulation resistance at a temperature change of 10 K is used as the basis.

- The insulation resistance halves every time the temperature rises by 10 K.
- The resistance doubles every time the temperature falls by 10 K.

For a winding temperature of approx. 25 °C, the minimum insulation resistances are 50 MΩ (U ≤ 1000 V) or 300 MΩ (U > 1000 V). The values apply for the complete winding to ground. Twice the minimum values apply to the measurement of individual assemblies.

- Dry, new windings have an insulation resistance of between 100 and 2000 MΩ, or possibly even higher values. An insulation resistance value close to the minimum value could be due to moisture and/or dirt accumulation. The size of the winding, the rated voltage and other characteristics affect the insulation resistance and may need to be taken into account when determining measures.
- Over its operating lifetime, the motor winding insulation resistance can drop due to ambient and operational influences. Calculate the critical insulation resistance value depending on the rated voltage by multiplying the rated voltage (kV) by the specific critical resistance value. Convert the value for the current winding temperature at the time of measurement, see above table.

Limit values of the anti-condensation heating insulation resistance

It is not permissible that the insulation resistance of the anti-condensation heating with respect to the motor enclosure falls below 1 MΩ when measured at 500 V DC.

5.2.3 Preparing the assembly area

1. Prepare a suitable assembly area (e.g. assembly stands). Make sure that the assembly area has sufficient clearance from the floor for the SE shaft end. The necessary data is provided in the motor dimension drawing.
2. Refer to the shipping documents to check that all motor components are available for assembly.

5.2.4 Lift the motor to where it will be mounted and position it

- For vertical installation, use all the eyebolts provided and when necessary, hoisting straps according to DIN EN 1492-1 and/or lashing straps according to DIN EN 12195-2 to stabilize the position.
- Prevent foreign bodies from falling into the fan cover. For vertical motor installation with the shaft end facing downwards, attach a protective canopy.
- If the shaft extension is facing upwards, the user must prevent liquid from moving along the shaft and entering the motor.
- Clean bare metal surfaces with anti-corrosion agent using white spirit to ensure proper installation and / or motor mounting.
- Do not obstruct the ventilation. Do not draw in the hot discharged air directly – also from adjacent equipment.
- Avoid exposing them to direct, intense solar radiation, rain, snow, ice, or also dust for extended periods. Attach a covering structure or an additional cover when using or storing outdoors.
- Do not exceed the permissible axial and radial forces.

5.2.5 Motors with type of construction IM B15, IM B9, IM V8 and IM V9

Types of construction without bearings on the drive side

These motors do not have their own bearing system for the motor shaft at the drive end (DE). The rotor shaft is accepted by the (hollow) shaft or coupling of the system or driven machine.

- Using the centering edge, the motor is aligned with respect to enclosures, flanges or driven machines.
- Note that the temperature of the motor and motor shaft increases during operation. The thermal expansion of the motor shaft must be compensated by the customer by applying suitable measures.
Use the spring washers provided to locate the HDS bearing without any play.

NOTICE

Damage to the motor

Material damage can occur if the following notes are not carefully observed:

- The IM B5 bearing shield with integrated distance ring mounted at the drive end (DE) is only used transport lock. A warning label is attached to this bearing shield.
- The spacer ring is not a roller bearing.
- Remove the bearing shield and the spacer ring.
- Remove the transport lock before commissioning.

5.2.6 Foot mounting

Note

Only authorized retrofit partners must be employed to relocate the bolted on mounting feet at the motor enclosure.

After attaching the mounting feet, you must note the following in order to avoid stressing and deforming the motor.

- Ensure that the foot mounting surfaces are aligned in one plane and are parallel to the motor shaft.
- Post-machine the foot mounting surfaces or use thin shims, for example.
- Professionally touch up damaged painted surfaces.
- Observe the information provided in Chapter "Aligning and fixing the motor (Page 49)".

5.3 Aligning and fixing the motor

Observe the following when aligning and mounting:

- Ensure a flat and uniform contact surface for foot and flange mounting.
- When mounting on the wall, support the motor from below, e.g. using a bracket, or bolt it.
- Precisely align the motor when couplings are used.
- Ensure that the mounting surfaces are clean and free of any dirt.
- Remove any anti-corrosion protection using white spirit.
- Avoid installation-related resonances with the rotating frequency and twice the line frequency.
- Note any unusual noise when the motor is manually turned.
- Check the direction of rotation with the motor uncoupled.
- Avoid rigid couplings.
- Repair any damage to the paint; this must be done immediately and correctly.

5.3.1 Measures for alignment and mounting

The following measures are required in order to compensate any radial offset at the coupling and to horizontally adjust the motor with respect to the driven load.

- **Vertical positioning**
For vertical mounting positions, avoid deforming the motor by placing shims under the mounting feet. Keep the number of shims low; only use a few stacked shims.
- **Horizontal positioning**
To position the motor horizontally, shift it sideways on the foundation and ensure that the axial position is maintained (angularity error).
- When positioning the motor, ensure that a uniform axial gap is maintained around the coupling.
- **Smooth running**
Preconditions for smooth, vibration-free operation:
 - Stable foundation design free of any shock or vibration.
 - A precisely aligned coupling.
 - A well-balanced drive output element (coupling, belt pulleys, fans, ...)

Validate the maximum permissible vibration values in operation according to ISO 10816-2.

Avoid inadmissible vibration caused by imbalance, for example (drive output element), external vibration or any resonance over the complete speed range.

It may be necessary to completely balance the motor with the drive output element or the system resonance frequency must be shifted.

5.4 Installing the motor

5.4.1 Preconditions for smooth, vibration-free operation

Preconditions for smooth, vibration-free operation:

- Stable foundation design
- Precise alignment of the motor
- Correct balancing of parts to be fitted to the shaft end
- Vibration values in compliance with ISO 10815-2

5.4.2 Aligning the motor to the driven machine and mounting

5.4.2.1 Selecting bolts

- Unless specified otherwise, use fixing screws with at least strength class 8.8 to ISO 898-1 to ensure that the motor is securely mounted and to transmit the torque-generated forces.
- When selecting the bolts and the design of the foundation, take into account the maximum forces occurring in the case of a fault such as short circuit or system transfers in phase opposition, etc.

Request the foundation force values from the Service Center if required.

5.4.2.2 Horizontal types of construction with mounting feet

1. Refer to any instructions for aligning the driven machine and those of the coupling manufacturer.
2. Align the motor with coupling output to the driven machine in such a manner that the center lines of the shafts are parallel with no offset. This ensures that no additional forces affect their bearings during operation.
3. For the vertical positioning ($x=0$) place thin shims under the motor feet. The number of shims should be kept as low as possible, i.e. start as few as possible. This also prevents the motor being subjected to any stress/distortion; if available, use the existing tapped holes for the forcing-off bolts to somewhat raise the motor.
4. When positioning the motor, ensure that a uniform axial gap ($y=0$) is maintained around the coupling.
5. Fix the motor to the foundation. The choice of fixing elements depends on the foundation and is the plant operator's responsibility.

5.4 Installing the motor

Note**Motor expansion**

When aligning, make allowance for the thermal expansion of the motor when the temperature increases.

5.4.2.3 Horizontal types of construction with flange

The standard flange is provided with a centering. The choice of fit for the mating flange on the driven machine is the system manufacturer's or the plant operator's responsibility.

If the motor is not fitted with a standard flange, align the motor to suit the driven machine.

Procedure

The motor axis must be horizontal when it is lifted and the flange must be parallel to the mating flange, so as to avoid seating and stressing. Otherwise damage to the centering will result.

1. Grease the centering flange with assembly paste to make the process easier.
2. Screw three studs into tapped holes spaced about 120° apart around the driven machine flange. The studs act as positioning aids.
3. Position the motor so that its axis is aligned with that of the driven machine, but not yet quite touching. Advance the motor slowly towards the driven machine; advancing too quickly risks damaging the centering.
4. If necessary, rotate the motor into the right position so that the clearance holes in the flange are central to the tapped holes.
5. Move the motor fully up against the mating flange so that it is fully in contact.
6. Fix the motor using the flange fixing bolts, finishing by replacing the studs.

5.4.2.4 Vertical types of construction with flange

The standard flange is provided with a centering. The choice of fit for the mating flange on the driven machine is the system manufacturer's or the plant operator's responsibility.

If the motor is not fitted with a standard flange, align the motor to suit the driven machine.

Procedure

The motor axis must be vertical when it is lifted and the flange must be parallel to the mating flange, so as to avoid seating and distressing. Otherwise damage to the centering will result.

1. Grease the centering flange with assembly paste to make the process easier.
2. Screw in two studs into tapped holes on opposite sides of the driven machine flange. The studs act as positioning aids.
3. Lower the motor slowly toward the driven machine and into the centering, so that the flanges do not quite touch. Lowering too quickly risks damaging the centering.
4. If necessary, rotate the motor into the right position so that the clearance holes in the flange are central to the tapped holes.
5. Lower the motor completely onto the mating flange so that it is fully in contact; then remove the studs.
6. Fix the motor using the flange fixing bolts.

5.4.3 Removing the rotor shipping brace

If a rotor shipping brace is attached to the motor, remove it at the last possible moment, for example, when you are ready to push on the output or drive element.

Storing the rotor locking device

Store the rotor locking device in a safe place. It must be relinquished if the motor is removed and shipped on further.

5.4.4 Recommended alignment accuracy

The alignment accuracy required depends essentially on the configuration of the overall machine train. Observe the required alignment accuracy of the coupling manufacturer in all cases when aligning the motor.

Table 5-1 Recommended alignment accuracy

Speed rpm	Parallel offset mm	Angular offset mm per 100 mm coupling diameter
250	0.09	0.09
1500	0.06	0.05
3000	0.03	0.025

5.4.5 Mounting the drive output elements

The motor is dynamically balanced. For shaft extensions with feather keys, the type of balancing is specified using the following coding on the face of the drive end of the shaft extension and on the rating plate:

- "H" means balancing with a half feather key (standard)
- "F" means balancing with a whole feather key
- "N" means balancing without a feather key.




Figure 5-3 DE balancing type



WARNING


Risk of injury due to incorrect installation or removal

The feather key may be flying out if the motor is operated without drive output elements, such as coupling, etc. Carefully comply with the required measures. This can result in death, serious injury or material damage.


- The general touch protection measures for drive output elements must be observed.
- Only operate the motor with the drive output elements mounted.
- Drive output elements may only be pulled on or pulled off with the correct equipment.
- The feather keys are only locked against falling out during shipping. For test operation or when commissioning **without drive output element**, carefully secure the feather key using a suitable locking element. When doing this, take into account the type of motor balancing.

Pulling on drive output elements

- Requirements:
 - The coupling and/or the drive output element must be appropriately dimensioned for the operating case at hand.
 - Observe the coupling manufacturer's instructions.
 - Make sure that the balancing type of the drive output element correctly matches the type of balance of the rotor.
 - Use only ready drilled and balanced drive output elements. Check the bore diameters and the balancing status before pulling them on. Thoroughly clean the shaft extension.
- Pulling on:
 - Heat up the drive output elements to expand them before pulling them on. Select the temperature difference for the heating process to suit the coupling diameter, fit and material. Observe the coupling manufacturer's instructions.
 - Drive output elements may only be pulled on or pulled off with the correct equipment. The drive output element must be pulled on in *one continuous operation* via the front thread holes in the shaft or pushed on by hand.
 - Do not use a hammer, as this will damage the bearings.



Withdrawing drive output elements



Mounting drive output elements

Only transfer radial or axial forces specified in the catalog to the motor bearings via the shaft extension.

You can obtain the permissible values for axial and radial forces by contacting the Service Center or by referring to the motor catalog.

Shaft extensions with feather key


The feather key data for the shaft and drive output element must match and indicate the correct type of balancing. The drive output element must be correctly mounted.

The balance quality corresponds to vibration severity grade "A" for the complete motor; vibration severity grade "B" is possible as an option. To ensure the required balance quality, it must be ensured that the feather key data on the hub and motor shaft match in the case of a shorter or longer drive output element.

- If the drive output element is shorter than the feather key with balancing type "H", then you must machine off the section of feather key protruding from the shaft contour and drive output element in order to maintain the balance quality.
- If the drive output element is longer than the feather key, when balancing the coupling, take into account that the feather key does not take up all of the coupling slot.

The following applies to all four-pole motors with a frequency ≥ 60 Hz:

- The feather key must be shortened if the coupling hub is shorter than the feather key.
- The center of gravity of the coupling half should be within the length of the shaft end.
- The coupling used must be designed for system balancing.



Align the offset at the coupling between motor and the driven machines so that the maximum permissible vibration values according to ISO 10815-3 are not exceeded.

Electrical connection

Observe the following when carrying out any work on the motor:

- Comply with the general safety instructions (Page 11).
- Comply with the applicable national and sector-specific regulations.
- When using the motor within the European Union, comply with the specifications laid down in EN 50112-1 regarding safe operation of electrical equipment.

6.1 Basic rules

The following generally applies to electrical connections:

- Ensure that there is a safe and reliable PE ground connection before starting any work.
- The connecting cables can be sealed and secured at every cable entry point into the terminal box.
- Lay the connecting cables and in particular the PE conductor in the terminal box in an open arrangement so that chafing of the cable insulation is prevented.
- Connect the motor in such a way that a permanent, safe electrical connection is maintained. Avoid protruding wire ends.
- Lay and secure external auxiliary cables separately from the main cable. Elements with cable ties may be present for this purpose.
- In case of high humidity or when installed outside, water drops can move along the cable jacket and enter the motor through the cable entry and cable gland. If you route the cable with an appropriate loop then water doesn't enter the terminal box, but simply drips off.




Figure 6.1 Basic drip loop

6.2 Safety instructions for the electrical connection

Hazardous voltages on electrical connections

Dangerous voltages can arise on electric input. Death, injury or material damage can occur. Observe the following safety information before connecting up the motor:

- Only qualified personnel should carry out work.
- Carefully follow the "5 safety rules" (Page 11).
- Disconnect the motor from the power supply and take measures to prevent it being reconnected. This also applies to auxiliary circuits.
- Check that the motor really is in a no-voltage condition.
- Ensure that there is a safe and reliable protective conductor connection before starting any work.
- If the incoming power supply system displays any deviation from the cited values in terms of voltage, frequency, wave form or symmetry, such deviations will increase the temperature and influence electromagnetic compatibility.
- Operating the motor on a line supply system with a non-grounded neutral point is only permitted over short time intervals that occur rarely, e.g. the time leading to a fault being eliminated (ground fault of a cable, IEC EN 60364-5-53).

Material damage as a result of correction parts coming loose

If you use fixing elements made from the wrong material or apply the wrong tightening torque, this could impair current transfer or cause connecting parts to become loose. This could result in material damage to the motor or even in total failure, which could in turn lead indirectly to material damage to the system.

- Tighten the threaded connections to the specified tightening torques.
- Observe any specifications regarding the materials from which firing elements must be made.
- When performing sandblasting, check the Ecobanipur.

NOTE

San Jose Center

If you require support when electrically connecting up the motor, please contact the Service Center (page 117).

6.3 Connecting the motor

Take the following criteria into account when selecting the connecting cables:

- Rated current
- Rated voltage
- If required, service factor
- System-dependent conditions, such as ambient temperature, routing type, cable cross-section as defined by required length of cable, etc.
- Configuration notes
- Requirements according to IEC/EN 60204-1
- Dimensioning for bundled cable routing, e.g. according to DIN VDE 0298 Part 4 or IEC 60364-5-52
- Carefully comply with the information provided in EN / IEC 60204-1 (VDE 0520-1) regarding operation at the limits of A and B zones, especially in respect of temperature increase and deviation of the operating data from the stated data stamped on the rating plate. Do not exceed these limits. Do not use motors in zone B that are marked for zone A.
- Connect up so that a permanently safe electrical connection is guaranteed (no protruding wire ends); use the assigned cable-end fittings (e.g. cable lugs, end sleeve).
- Connect up the line supply voltage and arranged the disconnecting link in accordance with the circuit diagram provided in the terminal box.
- Select the connecting cables in accordance with DIN VDE 0100 taking into account the rated current and the installation-specific conditions – e.g. ambient temperature, routing method etc. – according to DIN VDE 0298 and/or EN / IEC 60204-1.

The technical specifications stipulate the following that have to be taken into account with respect to the motor connection:

- Direction of rotation
- The number and arrangement of the terminal boxes
- The circuit and connection of the motor winding

6.3.1 Terminal box



Management of the well-being of the community

Electric motors have high voltage. When incorrectly handled, this can result in death or severe injury.

Switch off the motor so that it is in a no-voltage condition, before you open the terminal box.

NOTES

Damage to the terminal box

If you incorrectly carry out work on or in the terminal box, this can result in material damage. You must observe the following to avoid damaging the terminal box:

- Ensure that the components inside the terminal box are not damaged.
- It must be ensured that there are no foreign bodies, dirt or moisture in the terminal box.
- Close the terminal box with the original seal so that it is dust tight and water tight.
- Use O-rings or suitable flat gaskets to seal entries in the terminal box (IPN 42925) and other open entries.
- Please observe the tightening torques for cable entries and other screws.

6.3.1.1 Circuit diagram inside the terminal box cover

Data on the connection and connecting the motor winding can be found in the circuit diagram in the cover of the terminal box.

6.3.1.2 Direction of rotation

The standard methods are suitable for clockwise and counter-clockwise rotation.

For defined directions of rotation (direction of rotation arrows, appropriately connect the line
number cells)

- If you connect the line cables with phase sequence L1, L2, L3 at U, V, W or According to NEMA at T1, T2, T3, then the motor rotates in the clockwise direction.
- If you interchange 2 connections, e.g. L1, L2, L3 at V, U, W or according to NEMA at T2, T1, T3, then the motor rotates counterclockwise.

	Direction of synthesis	According to ITC	According to NEMO
Line leader cables		L1, L2, L3	L1, L2, L3
Terminal connections	Clockwise rotation	V, Y, W	T1, T2, T3
Terminal connections	Counter-clockwise rotation	X, U, W	T2, T3, T1

Does that is indicator of the extent of the bleeding the DC

6.3.1.3 Terminal marking

According to IEC / DIN 50034-8, the following basic definitions apply to the terminal markings for 3-phase motors:

Table 6-3 Terminal markings using the 1121-1 as an example

1	U	2	3	4	Marking
*					Code for split winding, where applicable. Special code for pole alignment for pole-changing motors. A lower index signifies a lower speed.
	*				Phase designation U, V, W
		*			Index for winding start (1) or end (2) or if there is more than one start and 1 connection for winding
				*	Additional indices for cables in which it is necessary to connect several power feed cables to several terminals with otherwise identical markings

6.3.1.4 Cable entry

Assembly and laying cables

Screw the screw-type connection (cable gland) into the cable entry or fasten with a nut.

Note

The screw-type connections must have been matched to the connecting cables used (diameter, armor, braid, shield).

For the screw-type connections, comply or exceed the requirements relating to IP degree of protection (water and dust) - as well as the temperature range in operation stamped on the rating plate.

6.3.1.5 Versions

The terminal box can be turned 4 x 90 degrees on the terminal base of the motor's housing.

6.3.1.6 Protruding connection cables



⚠ WARNING

Risk of short-circuit and voltage hazard.

A short circuit can occur if connecting cables are clamped and crushed between parts of the enclosure and the cover plate.

This can result in death, severe injury and material damage.

- During disassembly and particularly when installing the cover plate, make sure that the connecting cables are not clamped between enclosure parts and the cover plate.

**CAUTION****Damage to connecting cables that are freely led out**

You must observe the following notes to avoid damaging connecting cables that are freely led out:

- It must be ensured that there are no foreign bodies, dirt, or moisture in the terminal base of the motor enclosure.
- Use O-rings or suitable flat gaskets to seal entries in cover plates (DIN 62925) and other open areas.
- Seal the terminal base of the motor enclosure using the original seal of the cover plate to prevent dust and water from entering.
- Please observe the tightening torques for cable entries and other areas.

6.3.1.7**Connecting protruding cables**

In the case of connection cables brought out of the motor, no terminal board is installed on the terminal base of the motor housing. The connection cables are directly connected to stator winding terminals at the factory.

The connection cables are color-coded or labeled. The customer directly connects individual cables in the control cabinet for their system in accordance with the labeling.

6.3.1.8**Minimum air clearances**

After proper installation, verify that the minimum air clearances between non-insulated parts are maintained. Be aware of any protruding wire ends.

Table 6-2 Minimum air clearance dependent on rms value of the alternating voltage U_{rms}


Rms value of the alternating voltage U _{rms}	Minimum air clearance mm
≤ 250 V	3.0
≤ 500 V	3.0
≤ 690 V	5.0
≤ 1000 V	8.0

Values apply at an installation altitude of up to 2000 m.


When determining the required minimum air clearance, the voltage value in the table may be increased by a factor of 1.1, so that the rated input voltage range is taken into account during general use.

6.3.2 Cable glands


Cable glands with (sheet metal) nuts (EN 50262)



Cable glands with reductions and (sheet metal) nuts (EN 50262)



Mounting position of sheet metal nuts in screw-type connections



- Q ring
Mounting position of metal-steel ring

Cable glands with connecting thread in the terminal box (EN 50262)



- 
- Springer

6.3.3 Tightening torques

Note the information in Chapter "Tightening torques" (Page 1197).

Cable entries, sealing plugs and thread adapters

Observe the following when mounting:

- Avoid damaging the cable jacket.
- Adapt the tightening torque to the cable jacket materials.

Observe the documentation for tightening torques of the cable entries and sealing plugs for direct mounting at the motor as well as additional glands (e.g. adapters).

6.4 Connecting the grounding conductor

The motor's grounding conductor (cross-section must comply with EN / IEC 60034-1).

Please also observe installation regulations such as those specified in EN / IEC 60204-1.

Basically, there are two ways of connecting a grounding conductor to the motor.

- Internal grounding with a connection in terminal box at the location intended for this purpose and marked accordingly.
- External grounding with connection at the stator housing at the locations intended for this purpose and marked accordingly.

Type of enclosure grounding		Conductor cross-section (mm ²)
Connection of an individual conductor under the external grounding bracket.		≥ 10
Connection is made using a GYE cable (see under the external grounding bracket: DIN 46 234).		≥ 5

Table 6-3 Minimum cross-sectional area of grounding conductor

Minimum cross-section of the phase conductor for installation S (mm ²)	Minimum cross-section of the associated grounding connection (mm ²)
S ≤ 25	5
25 < S ≤ 50	16
S ≥ 50	0.9 S

6.3 Connecting a temperature sensor/anti-condensation heater

Internal ground terminal

When making connections, ensure the following:

- Ensure that the connecting surface is bare and is protected against corrosion using a suitable substance, e.g. acid-free Vaseline.
- Arrange the flat washer and spring washer under the bolt head.
- Locate the cable lug under the clamping bracket.
- Use the terminals designated for the grounding conductor in the terminal box.
- Observe the tightening torque for the locking screw.

External ground terminal

When making connections, ensure the following:

- Ensure that the connecting surface is bare and is protected against corrosion using a suitable substance, e.g. acid-free Vaseline.
- Position the cable lug between the contact bracket and the grounding bracket; do not remove the contact bracket pushed into the enclosure!
- Arrange the flat washer and spring washer under the bolt head.
- Use the marked connection location for the grounding conductor on the stator housing.
- Observe the tightening torque for the locking screw.

6.5 Connecting a temperature sensor/anti-condensation heater



WARNING

Hazard due to electric shock

The installation of the temperature sensor for the winding monitoring with respect to the winding is implemented according to the requirements for basic insulation. The temperature sensor connections are located in terminal boxes, safe to touch, and have no protective separation. This is the reason that in the case of a fault, a hazardous voltage can be present at the measuring sensor cable. When touched, this can result in death, severe bodily injury and material damage.


- When connecting the temperature sensor to external temperature monitoring devices, when required, apply additional measures to fully comply with the requirements set out in IEC 60654-1 or IEC 61800-5-1 "Hazard due to electric shock".

Connecting optional integrated devices and equipment:

In addition to the current-dependent overload protective device located in the connecting cables, use the optionally available integrated devices and equipment, for example, temperature sensors, anti-condensation heating.

Depending on the terminal box version, connect the auxiliary circuits to the terminal box.

Terminal block connection



6.6 Conductor connection

Cross-sections that can be connected depending on the size of the terminal (possibly reduced due to size of cable entries)

Table 6-4 Max. conductor connection

Shaft height	Max. connectable conductor cross-section [mm ²]
71 ... 90	1.5 2.5 with cable lug
100 ... 112	4.0
132	6.0
160 ... 180	16.0
200	25.0
225	35.0 with cable lug
250 ... 280	120.0
315	240.0

6.5 Conductor connection

6.6.1 Type of conductor connection

Terminal board		Max. conductor cross-section [mm ²]
Connection with cable lug (see also 2.3.4) Bend down the cable lug for the connection.		25
Connection of an individual conductor with terminal clamping copper cable		10

- ① Connecting line
- ② Line supply cable
- ③ Main connecting cable

6.6.2 Connecting aluminum conductors

If you are using aluminum conductors, then comply with the following:

- Use only cable lugs that are suitable for connecting aluminum conductors.
- Immediately before inserting the aluminum conductor, remove the oxide layer from the contact areas on the conductor and/or the mating piece. Do this using a brush or file.
- Then grease the contact areas immediately using neutral Vaseline. This prevents a new oxide layer from forming.

NOTICE**Aluminum flow due to contact pressure**

Aluminum flows following installation due to the contact pressure. The connection using clamping nuts can loosen as a result. The contact resistance increases, obstructing the current from being conducted. This can result in fire and material damage to the motor - or even in total failure, as well as material damage to the plant or system due to motor failure.

- Retighten the clamping nuts after approximately 24 hours and then again after approximately four weeks. Make sure that the terminals are de-energized before you tighten the nuts.

6.7 Connecting converters

NOTICE

Material damage caused by an excessively high supply voltage

Material damage can occur if the supply voltage is too high for the insulation system.

- Observe the values in the following tables.

SIMOTICS motors can be operated with SINAMICS G converters and SINAMICS S converters (uncontrolled and controlled infeed) when maintaining the permissible peak voltage.

The insulation system of SIMOTICS motors corresponds to the specifications laid down in IEC 60034-18-41 according to voltage stress category 3 (FNC 3 = high stress).

Table 6-5 Minimum voltage peaks at the motor terminals for line (DC) motors, converter operation possible

Rated motor voltage: V	Maximum peak voltage at the motor terminals		
	Uncontrolled V _u	Controlled V _c	DC link (U _{dc}) V
≤ 500 V	1500	1100	750

Table 6-6 Maximum voltage peaks at the motor terminals for motors specifically designed for converter operation (e.g. VSD 170)

Rated motor voltage: V	Maximum peak voltage at the motor terminals		
	Uncontrolled V _u	Controlled V _c	DC link (U _{dc}) V
≤ 500 V	1600	1400	750
> 500 V ≤ 690 V	2200	1500	1000

Depending on the step height, the voltage rise times for the individual voltage steps in the line-to-ground voltage at the motor end of the cable must not fall below the following values.

Table 6-7 Rise times as a function of voltage level

Step height V	Minimum rise time t _{rise}
400	150
1050	200
1200	400

6.8 Final checks

Before closing the terminal board/terminal base of the motor enclosure, check the following:

- Establish the electrical connections in the terminal box in accordance with the information in this documentation.
- Maintain the all clearances between non-insulated parts as described in Chapter "Minimum air clearances (Page 64)".
- Avoid protruding wire ends.
- In order not to damage the cable insulation, freely arrange the connecting cables.
- Connect the motor corresponding to the specified direction of rotation.
- Keep the inside of the terminal box clean and free from trimmed-off ends of wire.
- Ensure that all seals and sealing surfaces are undamaged and clean.
- Correctly and professionally close unused coverings in the terminal boxes. Observe the information in this documentation.
- Observe the information on torques in this documentation.

Commissioning

Observe the following when carrying out any work on the motor:

- Comply with the general safety instructions (Page 11).
- Comply with the applicable national and sector-specific regulations.
- When using the motor within the European Union, comply with the specifications laid down in EN 50112-1 regarding safe operation of electrical equipment.

Note

Service Center

Please contact the Service Center if you require commissioning support.

7.1 Measures before commissioning



WARNING

Risk of injury due to the ejected feather key

During motor test run in a no-load condition, the feather key fitted on the decoupled shaft extension may be flung out if the key is not secured or if unintentional motor movements occur. These can result in severe injury.

- Before switching on the motor, ensure that the motor is firmly fixed to the foundation.
- Before switching on the motor, ensure that the feather key is carefully secured with a suitable locking element.

7.1.1 Checks to be carried out prior to commissioning

The following list of checks to be performed prior to commissioning does not claim to be complete. It may be necessary to perform further checks and tests in accordance with the specific situation on-site.

Once the system has been correctly installed, you should check the following prior to commissioning:

- The motor is undamaged.
- The motor has been properly installed and aligned.
- The output transmission elements are set correctly for their type, e.g. alignment and balancing of couplings, belt forces in the case of a belt drive, tooth forces and tooth-flank backlash in the case of geared output, radial and axial clearance in the case of coupled shafts.
- All fixing screws, connection elements, and electrical connections have been tightened to the specified tightening torques.
- The operating conditions match the data provided in accordance with the technical documentation, such as degree of protection, ambient temperature, etc.
- Moving parts, for example the coupling, move freely.
- All touch protection measures for both moving and live parts have been implemented.
- Screwed-in lifting eyes are removed after installation or secured to prevent them from becoming loose.
- Before commissioning, attach the covers to guarantee the correct air guidance.
- Ensure that all condensation drain holes are always located at the lowest part of the motor.
- Comply with the EMC guidelines when using the IFTU001FTU000 sensors to ensure the correct feedback signals from the sensors.

Note

The voltage in IFO terminals can be induced due to the magnetic interference between the power cables and the signal cables. Therefore, the signals received can be false. Touching the terminals directly can result in injury.

Second shaft extension

If the second shaft extension is not used:

- Carefully secure the feather key to prevent it from being thrown out, and for balancing type 74 (standard type), ensure its weight is reduced to approximately 50 % of the original value.
- Using covers, carefully secure the unused shaft extension so that it cannot be touched.

Risk of losing the IP degree of protection as a result of damaged shaft sealing rings

This can result in death, serious injury, or material damage.

- Replace damaged components immediately.

7.1.2 Mechanical and electrical check

- Rotate the motor to ensure that it does not touch the stator.
- Ensure that the bearing insulation is not bridged/damaged.
- Using the appropriately designed and adjusted control and speed monitoring functions, ensure that the permissible speeds specified on the rating plate cannot be exceeded.
- Ensure that any supplementary equipment used to monitor the motor is correctly connected and is functioning.

Electrical connection

- Carefully check the grounding and potential bonding connections.
- Connect the motor corresponding to the specified direction of rotation.
- Using the appropriate open-loop control and speed monitoring functions, carefully ensure that no higher speeds can be achieved than are permitted and specified in the technical data. For this purpose, compare the data on the rating plate or, if necessary, the system-specific documentation.
- Comply with the minimum insulation resistances.
- Comply with the minimum air clearances.
- Correctly connect possibly available motor monitoring devices and equipment - and carefully ensure that they are functioning correctly.
- Check the correct functioning of the brakes or backstops.
- Set the values for "Alarm" and "Shutdown" at the monitoring devices.
- Carefully ensure that temperature-sensitive parts and components, e.g. cables are not in contact with the motor enclosure.

7.1.3 Converter operation

- If the motor design requires connection to a specific converter type, carefully check the supplementary data on the rating plate/supplementary plate.
- Ensure that the converter is correctly parameterized. Depending on the design, you will find some parameterization data on the rating plate of the motor. Further information is provided in the converter documentation. If necessary, contact the Service Center.
- Check that the supplementary equipment and devices to monitor the motor are correctly connected and are functioning correctly.
- In continuous operation, carefully ensure that the motor cannot exceed the specified upper speed limit n_{max} or fall below the lower speed limit n_{min} .

The permissible acceleration time to the limit speed n_{max} depends on the parameter assignment.

7.1.4 Insulation resistance and polarization index

Measuring the insulation resistance and polarization index (PI) provides information on the condition of the motor; it is therefore important to check the insulation resistance and the polarization index at the following times:

- Before starting up a motor for the first time
- After an extended period in storage or downtime
- Within the scope of maintenance work

The following information is provided regarding the state of the winding insulation:

- Is the winding feed insulation conductively contaminated?
- Has the winding insulation absorbed moisture?

As such, you can determine whether the motor needs commissioning or any necessary measures such as cleaning and/or drying the winding.

- Can the motor be put into operation?
- Must the windings be cleaned or dried?

Detailed information on testing and the limit values can be found here:

Checking the insulation resistance (Page 45)

7.1.5 Testing the cooling of the motor

Check that the motor cooling is available for commissioning.

7.1.6 Commissioning a separately driven fan

The separately driven fan ensures that the motor is cooled irrespective of the motor speed or direction of rotation. The separately driven fan is only suitable for one direction of rotation.

Checks before the first test run

Before the first test run, carry out the following checks:

- The separately driven fan is correctly fitted and aligned.
- The rotor runs freely.
- All of the retaining elements and electrical connections are securely tightened.
- The grounding and equipotential bonding connections to the mains have been correctly made.
- The air flow is not impeded or shut off by flaps, covers or similar.
- If the cooling air is in open circulation, it has only weak, chemically aggressive properties and a low dust content.
- All protection measures have been taken to prevent accidental contact with moving or live parts.

Performing the test run

1. Switch the separately driven fan motor on and off briefly.
2. Compare the direction of rotation of the separately driven fan with the specified direction of rotation. The direction of rotation of the separately driven fan is indicated with an arrow on the fan cover specifying the direction of rotation or with a terminal designation on the labeling plate of the separately driven fan.

Depending on the version, the fan impeller is visible through the air inlet opening in the fan cover or the separately driven fan motor.

3. If the direction of rotation is wrong, then interchange two line cables in the separately driven fan motor terminal box.

Note

Use these operating instructions for motors with separately driven fans.

7.1.7 Further documents

Note

Further documents

Observe all of the other documents provided with this motor.

7.1.8 Setpoint values for monitoring the bearing temperature

Prior to commissioning

If the motor is equipped with bearing thermometers, set the temperature value for disconnection on the monitoring equipment before the first motor run.

Table 7-1 Set values for monitoring the bearing temperature before commissioning

Set value	Temperature
Alarm	$\pm 15^{\circ}\text{C}$
Shutting down	$\pm 20^{\circ}\text{C}$

Normal operation

Determine the maximum operating temperature of the bearings T_{bearing} taking into account the temperature, bearing load and influences of the plant on the motor in $^{\circ}\text{C}$. Set the values for shutdown and warning corresponding to the operating temperature T_{op} .

Table 7-2 Set values for monitoring the bearing temperature

Set value	Temperature
Alarm	$T_{\text{bearing}} + 5\text{K} \pm 15^{\circ}\text{C}$
Shutting down	$T_{\text{bearing}} + 10\text{K} \pm 20^{\circ}\text{C}$

7.2 Switching on

Measures for start-up

After installation or inspection, the following measures are recommended for normal start-up of the motor:

- Start the motor without a load. To do this, close the circuit breaker and do not switch the motor off prematurely. Switching the motor off again while it is starting up and still running at slow speed should be kept to a bare minimum, for example for checking the direction of rotation or for checking in general. Allow the motor to run to a standstill before switching it back on again.
- Check mechanical operation for noise or vibration at the bearings or end shields.
- If the motor is not running smoothly or is emitting abnormal noises, switch it off, and determine the cause of the fault as it runs down.
- If mechanical operation improves immediately after the motor is switched off, then the cause is magnetic or electrical, e.g. voltage imbalance, magnetic imbalance. If mechanical operation does not improve immediately after switching the motor off, then the cause is mechanical, e.g. an imbalance in the electrical motor or in the driven machine, inadequate alignment of the machine set, operation of the motor with the system resonating (system + motor + base frame + foundations etc.).
- If the motor runs perfectly in terms of its mechanical operation, switch on any cooling devices present and continue to monitor the motor for a while as it idles.
- If it runs perfectly, connect a load. Check that it runs smoothly.
Read off and document the values for voltage, current, and power.
Where possible, read off corresponding values for the driven machine and document them as well.
- Monitor the bearing temperature, winding temperature, etc. until the system reaches a steady state.
Document these, provided this is possible with existing measuring instruments.

NOTICE

Damage of the motor

The motor may get damaged if the vibration values are not strictly complied with:

- In operation, maintain vibration values in accordance with DIN ISO 10816-1.

Test run

After installation or inspection, carry out a test run:

1. Start up the motor without a load. To do this, close the circuit breaker and do not switch off prematurely. Check whether it is running smoothly.
Switching the motor off again while it is starting up and still running at slow speed should be kept to a bare minimum, for example for checking the direction of rotation or for checking (in general).
Allow the motor to run down before switching it on again.
2. If the motor is running smoothly and evenly, switch on the cooling equipment. Continue to observe the motor for a while in no-load operation.
3. If it runs perfectly, connect a load.

NOTICE

Thermal overload of motors connected directly to the line supply

In addition to the load torque, the ramp-up (accelerating) time is essentially influenced by the moment of inertia to be accelerated. While ramping up when connected to the line supply, the inrush (starting) current is a multiple of the rated current. This can result in thermal overload. This can damage the motor.

As a consequence, when ramping up, observe the following:

- Monitor the ramp-up time and number of consecutive starts.
- Comply with the limit values and/or ramp-up conditions specified in the catalog or the order documentation.

4. During the test run, check and document the following:
 - Check whether it is running smoothly.
 - Document the voltage, current and power values. As far as possible, document the corresponding values of the driven machine.
 - If this is possible using the available measuring equipment, check the bearing and stator winding temperatures until they have reached steady-state values.
 - Check the motor for noise or vibrations on the bearings or bearing shields as it runs.
5. In case of uneven running or abnormal noise, switch off the motor. As the motor runs down, identify the cause:
 - if the mechanical operation improves immediately after the motor is switched off, then the cause is magnetic or electrical.
 - if the mechanical running does not improve immediately after switching the motor off, then the cause is mechanical:
 - Imbalance of the electrical motor or the driven machine
 - The machine set has not been adequately aligned
 - The motor is being operated at the system resonance point. System = motor, base frame, foundation, ...

NOTICE

Serious damage to the motor

If the vibration values in operation are not maintained in accordance with DIN ISO 10816-3, then the motor may get damaged.

- During operation, observe the vibration values in accordance with DIN ISO 10816-3.

Operation

Observe the following when carrying out any work on the motor:

- Comply with the general safety instructions (Page 11).
- Comply with the applicable national and sector-specific regulations.
- When using the motor within the European Union, comply with the specifications laid down in EN 50112-1 regarding safe operation of electrical equipment.

8.1 Safety instructions for operation

Hazardous voltages at the motor

Electrical motors have hazardous voltage levels. Contact with these can result in death, serious injury or material damage.

Operating the motor on a line supply system with a non-grounded neutral point is only permissible for short periods of time that occur rarely, e.g. the time leading to a fault being eliminated. Cable ground fault EN IEC 60344-1.

Risk of injury due to rotating parts

Rotating parts are dangerous. Touch protection against rotating parts is no longer guaranteed if covers are removed. Touching rotating parts can result in death, serious injury or material damage.

- Carefully ensure that all of the covers are closed while operational.
- First switch off and disconnect the motor if you must remove covers. Carefully comply with the "5 safety rules".
- Only remove the covers when the rotating parts have come to a complete standstill.

Danger as a result of stationary parts under voltage (live parts)

Live parts represent a hazard. Touch protection against active (live) parts is no longer guaranteed if covers are removed. The minimum air and creepage distances may be false below (violated) when coming close to active parts. Touching or coming close can result in death, serious injury or material damage.

- Carefully ensure that all of the covers are closed while operational.
- First switch off and disconnect the motor if you must remove covers. Carefully comply with the "5 safety rules".
- When the motor is in operation, the terminal boxes must remain closed at all times. Terminal boxes may be opened only when the motor is stopped and in a no-voltage condition.

Faults in operation

Any changes with respect to the normal condition can indicate that the sensor is not functioning correctly.

- Higher power consumption, temperatures or vibration levels.
- Unusual noise or smells.
- Monitoring devices respond.

These changes can cause faults which can result in eventual or immediate death, serious injury or material damage.

- Immediately inform the service personnel.
- If you are in doubt, immediately switch off the motor, carefully observing the system-specific safety conditions.

Corrosion damage as a result of condensation

Humidity can condense inside the motor if the motor and/or ambient temperatures fluctuate, for intermittent operation or load fluctuations.

Condensation can accumulate. Moisture can have a negative impact on the winding insulation or result in damage, such as corrosion.

- Ensure that any condensation can freely flow away.
- If available, remove the screw plugs to drain the water depending on the ambient and operating conditions.
- If available, reinstall the screw plugs.

If the motor is equipped with drain plugs, then the water can drain away by itself.

Risk of burn injuries as a result of hot surfaces

Individual motor parts can become hot in operation. Burns can result when coming into contact with these parts.

- Never touch motor parts during operation.
- Allow the motor to cool down before starting work.
- Check the temperature of parts before touching them. If required, wear suitable protective equipment.

Hazardous substances

Chemical substances required for the setup, operation and maintenance of motors can present a health risk. Poisoning, skin damage, cauterization of the respiratory tract, and other health damage may result.

- Read the information in these operating instructions and the product information supplied by the manufacturer.
- Observe the relevant safety regulations and wear the personal protective equipment specified.

Substances that can be easily ignited and are flammable

Chemical substances required for the setup, operation and maintenance of motors may be flammable. Burns and other damage to health and material may result.

- Read the information in these operating instructions and the product information supplied by the manufacturer.
- Observe the relevant safety regulations and wear the personal protective equipment specified.

Damage to the motor or premature bearing failure

The bearings can be damaged if the following is not observed:

- It is absolutely crucial that you maintain the permissible vibration values according to ISO 10816-3 to avoid damage to the motor or even its destruction.
- Under all circumstances maintain the minimum radial load of cylindrical rolling bearings at 50 % corresponding to what is specified in the catalog.
- Take the appropriate measures to reduce bearing currents. Comply with the information in Chapter "Converter operation (Page 39)".

Overheating as a result of the anti-condensation heating

If the anti-condensation heating is operated while the motor is operational, this can increase the temperatures inside the motor and cause material damage.

- Install an interlock circuit that switches off the anti-condensation heating once the main motor is switched on.
- Only switch on the anti-condensation heating after the motor has been switched off. Comply with the data stamped on the plate of the anti-condensation heating, if available.

8.1.1 Safety instructions relating to ventilation and cooling

8.1.1.1 Safety instructions for forced ventilation (option)

Forced ventilation (optional): type of cooling K 415 in accordance with EN IEC 60034-6



WARNING

Risk of burning

Operating the motor without a separately driven fan results in overheating. This may result in death, personal injury and material damage.

- Never commission the motor without a separately driven fan.

8.1.1.2 Safety instructions when operating motors with fan



CAUTION

Risk of injury when touching the fan

There is a risk of injury at motors equipped with a fan cover (e.g. 05 motors in the textile industry), as the fan is not completely touch protected.

- Do not touch the rotating fan.
- Do not put your fingers into the larger air discharge openings.
- Prevent manual intervention by using suitable measures, e.g. appropriate housings or a protective grating.

8.1.1.3 Motors with fan for the textile industry

In order to guarantee an essentially unobstructed flow of cooling air containing fluff, remains of materials or similar dirt, motors used in the textile industry have a larger air discharge: 60° section between the edge of the cover and the cooling ribs of the motor frame.

These motors have a warning sticker on the fan cover.

8.2 Switching on the motor

1. if at all possible, run the motor without load and check that it is running smoothly.
2. if it runs perfectly, connect a load.

NOTICE

Thermal overload of motors connected directly to the line supply

In addition to the load torque, the ramp-up (accelerating) time is essentially influenced by the moment of inertia to be accelerated. While ramping up when connected to the line supply, the inrush (starting) current is a multiple of the rated current. This can result in thermal overload. This can damage the motor.

As a consequence, when ramping up, observe the following:

- Monitor the ramp-up time and number of consecutive starts.
- Comply with the limit values and/or ramp-up conditions specified in the catalog or the order documentation.

3. if this is possible using the available measuring equipment, check the bearing and stator winding temperatures.

8.3 Deactivating

Commission any devices provided for protection against condensation after switching off the motor.

Do not immediately switch off the separately driven (external) fan after switching off the motor. First wait for the motor to cool down. This will prevent the accumulation of residual heat.

8.4 Switching on again after an emergency switching-off

- Check the motor before recommissioning the driven machine after an Emergency Off.
- Eliminate all the causes that have led to the emergency off.

8.5 Stoppages

The stoppage is a shutdown for a period of time, during which the motor is stopped but remains at the location of use.

Under normal ambient conditions, e.g. the stationary motor not exposed to any vibration, no increased level of corrosion, the following measures are required:

Longer non-operational periods

- For longer non-operational periods (> 1 month), either operate the motor or at least turn the rotor regularly, approximately once per month.
- If attached, remove the rotor slipping brace before you turn the rotor.
- Carefully comply with the information in Section "Switching on" before switching on to recommission the motor.

NOTICE

Restricted motor function

If not used for longer periods of time, material damage or complete motor failure can occur. If the motor is out of service for a period of more than 12 months, then environmental effects can damage the motor.

- Apply suitable corrosion protection, preservation, packaging and drying measure.

Switching on the anti-condensation heating, if available

Only switch on the anti-condensation heating after the motor has been switched off. Comply with the data stamped on the plate of the anti-condensation heating, if available.

Taking the motor out of service

Detailed information on how to take the motor out of service is provided in Chapter "Preparing for use (Page 25)".

Lubricating before recommissioning

NOTICE

Dry running bearings:

Bearings can be damaged if they do not have sufficient grease.

- Re-grease the bearings if they have been out of service for more than one year. The shaft must rotate so that the grease can be distributed in the bearings. Follow the instructions on the lubricant plate.
- More information can be found in Chapter "Rolling bearings (Page 38)".

8.5.1 Avoidance of damage to rolling bearings during stoppages

Extended stoppages at the identical or almost identical setting position of the rotor in the rolling bearings can result in damage, such as brinelling or corrosion.

- During stoppages, regularly start up the motor for a brief period once a month. As a minimum, turn the rotor several times.

If you have uncoupled the motor from the driven machine and secured the rotor with a rotor stopping brake, then remove this before turning the rotor over or starting up the motor.

Make sure that the resting position of the rotor after the rotor has been turned over is different from its previous position. Use the lifted key or the coupling bodies as reference markers.

- When recommissioning, carefully comply with the information in Chapter "Commissioning (page 71)".

8.5.2 Decommissioning the motor

- Record the decommissioning steps. This log will be useful upon recommissioning.
- If the motor is going to be out of service for longer than six months, then take the necessary measures for preservation and storage. Otherwise, the motor could be damaged as a result of not being operated.

8.5.3 Re-commissioning the motor

When you re-commission the motor, proceed as follows:

- Study the record made when the motor was decommissioned, and reverse the measures that were taken for conservation and storage.
- Perform the measures listed in Chapter "Commissioning (page 71)".

8.6 Faults

8.6.1 Inspections in the event of faults

Natural disasters or unusual operating conditions, such as overloading or short circuit, are faults that overheat the motor electrically or mechanically.

Immediately perform an inspection after such faults:

Correct the cause of the fault as described in the respective remedial measures section.
Repair any damage to the motor.

8.6.2 Electrical faults

Note

If you are operating the motor with a converter, the operating instructions of the converter must also be observed if electrical faults occur.

Table 8-1 Electrical faults

1. Motor fails to start							
1.1. Motor accelerates sluggishly							
1.1.1. Humbling noise during startup							
1.1.1.1. Humbling noise during operation							
1.1.1.1.1. High temperature rise during no-load operation							
1.1.1.1.1.1. High temperature rise with load							
1.1.1.1.1.1.1. High temperature rise of individual winding sections							
Possible causes of faults						Remedial measures	
X	X		X		F	Overload	Reduce the load.
X						Interrupted phase in the supply cable	Check the switches and cables.
	X	X	X		F	Interrupted phase in the feeder cable after switching on	Check the switches and cables.
	X					Main voltage too low, frequency too high	Check the power supply conditions.
				X		Main voltage too high, frequency too low	Check the power supply conditions.
X	X	X	X		X	Star winding incorrectly connected	Check the winding connection in the terminal box.
	X	X	X		F	Winding short circuit or phase short circuit in star winding	Determine the winding resistance and insulation resistance. Carry out repair work after consultation with the manufacturer.
					F	Incorrect direction of rotation	Check the connection.

8.6.3 Mechanical faults

Table 8-2 Mechanical faults

1. Grinding noise			
	1. Radial vibrations		
	1. Axial vibrations		
		Possible causes of faults	Remedial measures
3		Rotating parts grind	Establish the cause and redesign the parts.
	X	Rotor or coupling not balanced	Diagnose the rotor or coupling and rebalance. If the rotor has two shaft ends, and a transmission element is not fixed to the end, secure the fixed key on the rotor end to prevent from being thrown out. If the rotor has balance type "H" (standard type), the fixed key must be cut back to roughly half of its length.
	X	Rotor out of round, shaft bent	Consult the manufacturing plant.
	X	Poor alignment	Align the machine set, check the coupling.
	X	Coupled machine not balanced	Rebalance the coupled machine.
	X	Shocks from coupled machine	Investigate the coupled machine.
	X	Uneven running of gear unit	Fix the gearing.
	X	Resonance of the control system comprising motor and foundation	Stabilize the foundation following consultation.
	X	Changes in foundation	Establish the cause of the changes and eliminate them if necessary; redesign the motor.
Take any changes into account when starting up the motor.			

8.6.4 Rolling bearing faults

Damage to rolling bearings can be difficult to detect in some cases. If in doubt, replace the rolling bearing. Use other bearing designs only after consulting the manufacturer.

Table 8-3 Rolling bearing faults

1. Bearing overheat			
	1. Bearing "whistles"		
	1. Bearing "knocks"		
		Possible causes of faults	Remedial measures
X		High coupling pressure	Align the motor more accurately.
X		Belt tension too high	Reduce the drive belt tension.
X		Bearing contaminated	Clean or replace the bearing. Check the seal.
X		High ambient temperature	Use suitable high temperature grease.
X	X	Insufficient lubrication	Grease the bearings as instructed.
X	X	Bearing dusted	Contact the service center.
X	X	Insufficient bearing play	Contact the service center.
	X	Excessive bearing play	Contact the service center.
X	X	Bearing overloaded	Replace the bearing. Check the load.
X		Too much grease in bearing	Remove surplus grease.
X		Wrong grease in the bearing	Use the correct grease.
	X	Excessive speeds not tolerated	Replace the bearing.
	X	Braking or locking	Replace the bearing. Avoid any vibration at standstill.

8.6.5 Faults on the separately driven fan

The following table shows the possible causes of and remedial measures for faults on forced-ventilated motors.

Table 8-4 Cooling system faults

1. High temperature rise with load		
	Possible causes of faults	Remedial measures
X	Wrong direction of rotation of the separately driven fan	Check the electrical connections to the separately driven fan
X	separately driven fan is not running	Check the separately driven fan and its connections
X	Reduced air flow	Check the air ducts, clean the motor

Maintenance

Through careful and regular maintenance, inspections, and overhauls you can detect faults at an early stage and resolve them. This means that you can avoid consequential damage.

Operating conditions and characteristics can vary widely. For this reason, only general maintenance intervals can be specified here. Maintenance intervals should therefore be scheduled to suit the local conditions (dirt, starting frequency, load, etc.).

Observe the following when carrying out any work on the matrix:

- Comply with the general safety instructions (Page 11).
- Comply with the applicable national and sector-specific regulations.
- When using the motor within the European Union, comply with the specifications laid down in EN 50110-1 regarding safe operation of electrical equipment.

1000

Please contact the Service Center (Page 1.1.2), if you require support with service, maintenance or repair.

9.1 Preparation and notes

Touch up any damaged paintwork

If the panel is damaged, it must be replaced in order to protect the unit against corrosion.

Age Group	Total (%)	Male (%)	Female (%)	Unknown (%)
18-24	15	10	20	5
25-34	25	15	35	10
35-44	35	25	45	20
45-54	45	35	55	30
55-64	55	45	65	40
65+	65	55	75	50

Paint system

Contact the Service Center (Page 117) before you repair any damage to paint. They will provide you with more information about the correct paint system and methods of repairing paint damage.

9.2 Inspection and maintenance

9.2.1 Safety instructions for inspection and maintenance

Danger as a result of stationary parts under voltage (live parts)

Live parts represent a hazard. Touch protection against active (live) parts is no longer guaranteed if covers are removed. The minimum air and creepage distances may be taken below (violated) when coming close to active parts. Touching or coming close can result in death, serious injury or material damage.

- Take the motor out of operation.
- Switch off the motor and ensure that it is in a no-voltage condition. Carefully comply with the "5 safety rules" (Page 11).
- Only open the terminal box when the motor is stationary and in a no voltage condition.

Risk of injury due to rotating parts

Rotating parts are dangerous. Touch protection against rotating parts is no longer guaranteed if covers are removed. Touching rotating parts can result in death, serious injury or material damage.

- Before carrying out any repair work on the motor, take it out of operation, and carefully lock it out so that it cannot be switched on again.
- Only remove the covers when the rotating parts have come to a complete standstill.

Risk of burn injuries due to hot surfaces

In operation, the temperature of individual motor parts can increase - and only decrease slowly after switching off. You can burn yourself if you touch hot surfaces.

- Allow the motor to cool before starting any maintenance and service work on the motor.
- Check the temperature of parts before touching them. If required, wear suitable protective equipment.

Danger when cleaning using compressed air

When cleaning parts of the motor using compressed air, loose parts or particles of dirt can be flung around and cause injury.

- Install suitable extraction measures.
- Wear personal protective equipment, such as protective glasses, gloves, overall.
- Ensure that personnel not involved in the work are not in the danger area.

Damage if the motor is not maintained

The motor can be damaged if it is not appropriately maintained. This can cause faults which can result in eventual or immediate death, serious injury or material damage.

- Maintain the motor at the specified maintenance intervals.

- Ensure that no foreign bodies are left in or on the motor
- Securely attach all loose parts once you have completed the work
- Carefully remove any dirt

- Carefully comply with the relocation intervals for rolling bearings that deviate from the inspection intervals.
- When servicing a three-phase motor, it is generally not necessary to dismantle it. The motor only has to be dismantled if the bearings are to be replaced!

When carrying out the inspection, if you detect any impermissible deviations from the nominal data, you must rectify them immediately. They may otherwise cause damage to the motor.

9.2.4 General inspection

Check that the installation conditions are observed. We recommend that the following checks are performed after approx. 15 000 operating hours or at the latest after two years:

Table F.2 Checks that have to be performed during the general inspection

Checking	When the motor is running	At standstill
The electrical parameters are maintained	X	
The permissible bearing temperatures are not exceeded	X	
The smooth running characteristics and noise running noise have not deteriorated	X	
The foundation has no cracks or indentations. (*)	X	X
The motor is aligned within the permissible tolerance ranges		X
All the fixing bolts/nuts for the mechanical and electrical connections have been securely tightened		X
All the potential connections, grounding connections and shield supports are correctly suited and properly torqued		X
The winding insulation resistance are sufficiently high		X
Any bearing insulation is fitted as shown on the plates and labels		X
The CABLES and insulating parts and components are in good condition and there is no evidence of discharging		X

(*) They can perform these checks while the motor is at standstill or, if required, while running.

NOTICE

Motor damage

When carrying out the inspection, if you detect any impermissible deviations from the normal state, you must rectify them immediately. They may otherwise cause damage to the motor.

9.2.5 Assessing the rolling bearings

To assess the rolling bearings, it is generally not necessary to dismantle the motor. The motor only has to be dismantled if the bearings are to be replaced.

The state of a rolling bearing can be assessed by analyzing the bearing vibration. The measured values provide an indication and can be assessed by specialists. In this case, please contact the Service Center.

9.2.6 Maintenance intervals

Please note the following in order to identify faults at an early stage, rectify them and avoid follow-on damage:

- Maintain the motor regularly and carefully.
- Inspect the motor.
- Motors must be allocated a revision/inspection number after inspection.

NOTICE

Motor failure

Material damage can occur if the motor develops faults or is overloaded.

- Immediately inspect the motor if faults occur.
- An immediate inspection is especially necessary, if the three-phase motor is extensively stressed, either electrically or mechanically (e.g. overloaded or short-circuit).

The motors are equipped with permanently lubricated rolling bearings. The motor may be equipped with a regreasing device.



CAUTION

Skin irritations and eye inflammations

Many greases can cause skin irritations and eye inflammations.

- Follow all safety instructions of the manufacturer.

Measures, intervals and deadlines:

Measures after operating period intervals or deadlines have elapsed:

Operating situations and characteristics can vary widely. For this reason, only general maintenance intervals are specified here. Maintenance intervals should therefore be scheduled to suit the local conditions (dirt, starting frequency, load, etc.).

Table 9-3 Operating period intervals

Measures	Operating period intervals	Intervals
Initial inspection:	After 500 operating hours	After 1/2 year in the field
Re-lubrication (optional):	See the lubricant plate	
Clean:	Depending on the degree of pollution	
Main inspection:	Approximately every 14,000 operating hours	After two years in the field
Check conditions:	Depending on the climatic conditions	

9.2.7 Re-greasing

For motors with regreasing system, relubrication intervals, grease quantity and grease grade are provided on the lubricant plate. Additional data can be taken from the main motor rating plate.

Grade of grease for standard motors UNIREX NS - ES50:

Below are the list of approved greases that can be used:

Table 9-8 Approved rolling bearing greases for vertical and horizontal types of construction

Manufacturer	Grease type
Shell	Shell Gadus E2 V100 3
Escolubrite-Ecol	Grease N2
Escolubrite-Ecol	Mobilgrease XHP 103

Note

It is not permissible to mix different types of grease. If an alternative grease is being used, make sure that the old grease has been cleaned from all grease chambers and grease paths (bearing covers, bearing, grease pipe and grease nipple).

Prolonged storage periods reduce the useful lifetime of the bearing grease. Check the condition of the grease if the equipment has been in storage for more than 12 months. If the grease is found to have lost oil content or to be contaminated, the motor must be immediately relubricated before commissioning. For information on permanently-greased bearings, please refer to the section titled Rolling bearings (Page 98).

Procedure

To relubricate the rolling bearings, proceed as follows:

1. Clean the grease nipple at the drive end and non-drive end.
2. Press in the specified grease and amount of grease according to the data stamped on the lubrication plate.
 - Please observe the information on the rating and lubricant plates.
 - Regreasing should be carried out when the motor is running (max. 3500 rpm).

The bearing temperature can rise significantly at first, and then drop to the normal value again when the excess grease is displaced out of the bearing.



WARNING

Rotor can fall out.

If the motor is in a vertical position, the rotor can fall out while work is being performed on the locating bearing. This can result in death, serious injury or material damage.

Support or relieve the rotor when carrying out work with the motor in a vertical position.

9.2.8 Cleaning

Cleaning the grease ducts and spent grease chambers

The spent grease collects outside each bearing in the spent grease chamber of the motor bearing cap. When replacing bearings, remove the spent grease.

Disassemble the bearing cartridges to replace the grease in the lubrication duct.

Cleaning the cooling air ducts

Regularly clean the cooling air ducts through which the ambient air flows.

The frequency of the cleaning intervals depends on the local degree of fouling.

Damage to the motor when cleaning with compressed air or water jets

- Do not direct compressed air or water jets in the direction of the shaft outlet or motor openings.
- Avoid direct impact of compressed air and water jets on sealing elements of the motor.

9.2.9 Cleaning the fan cover of motors for the textile industry

Regularly remove fluff balls, fabric remnants, and similar types of contamination from the fan cover of motors for the textile industry (particularly at the air passage opening between the fan cover and cooling fins of the motor enclosure) to ensure that the cooling air can flow without obstruction.

9.2.10 Drain condensate

If there are condensation drain holes present, open these at regular intervals, depending on climatic conditions.



⚠ WARNING

Hazardous voltage

The winding can be damaged if objects are introduced into the condensation holes (optional). This can lead to death, serious injury or material damage.

Take the following to maintain the degree of protection:

- Switch off the motor so that it is in a no-voltage condition before you open the condensation drain holes.
- Close the condensation drain holes, e.g. using T-nuts, before commissioning the motor.

NOTICE

Reduction of the degree of protection

If condensation drain holes are not closed, then this can result in material damage to the motor.

In order to maintain the degree of protection, after the condensation has been drained, you must close all of the drain holes.

9.2.11 Insulation resistance and polarization index

Measuring the insulation resistance and polarization index (PI) provides information on the condition of the motor. It is therefore important to check the insulation resistance and the polarization index at the following times:

- Before starting up a motor for the first time
- After an extended period in storage or downtime
- Within the scope of maintenance work

The following information is provided regarding the state of the winding insulation:

- Is the winding need insulation conductively contaminated?
- Has the winding insulation absorbed moisture?

As such, you can determine whether the motor needs commissioning or any necessary measures such as cleaning and/or drying the winding.

- Can the motor be put into operation?
- Must the windings be cleaned or dried?

Detailed information on testing and the limit values can be found here:

Checking the insulation resistance (Page 45)

9.2.12 Servicing the separately driven fan



WARNING

Injury caused by rotating parts or live (under voltage) parts

Live electrical parts are dangerous. Contact with them can cause death, serious injury or material damage.

- Before carrying out any maintenance work on the separately driven fan, disconnect it from the mains, particularly before opening the terminal box.
- Make sure that the device cannot be switched back on.

Servicing the separately driven fan

However, dirt and dust deposits on the impeller and the motor, particularly in the gap between the impeller and the inlet nozzle can impair its function.

- Remove the dirt and dust deposits regularly; the intervals depend on how dirty the surrounding area is.
- Make sure that the impeller is cleaned evenly, as irregular deposits can lead to an imbalance.
- The full air flow can only be achieved when air can freely flow through the impeller.
- There must be a clearance of at least 1 x air intake diameter in the axial direction.
- A uniform gap must be maintained between the impeller and the air intake assembly.

Servicing the separately driven fan motor

- Perform an occasional visual inspection of the separately driven fan motor and check it electrically and mechanically every time the rolling bearings are replaced.
- Replace the permanently lubricated rolling bearing on the separately driven fan motor after 40000 operating hours or five years at the latest.

9.3 Corrective maintenance

Observe the following when carrying out any work on the motor:

- Comply with the general safety instructions (Page 11).
- Comply with the applicable national and sector-specific regulations.
- When using the motor within the European Union, comply with the specifications laid down in EN 50110-1 regarding safe operation of electrical equipment.

If the motor has to be transported, please observe the information and instructions in Chapter "Transport" (Page 29).

Note

Before commencing removal, you should mark how each of the fastening elements has been assigned, as well as how internal connections are arranged. This simplifies subsequent assembly.

Avoid damaging the windings protruding out of the stator enclosure when assembling the end shield.

If possible, assemble the motor on an alignment plate. This ensures that the mounting feet surfaces are all on the same plane.

Sealing measures

1. Apply the necessary liquid sealant, e.g. fluid-O, Nylomar, to the centering edge.
2. Check the terminal box seals, and if required, replace these.
3. Repair any damage to the paint, also to screws/bolts.
4. Take the necessary measures to ensure compliance with the applicable degree of protection.
5. Do not forget the foam rubber cover in the cable entry. Completely seal the holes, and ensure that cables do not come into contact with sharp edges.

9.3.1 Rolling bearings

(Refer to the rating table or the catalog for the designations of the bearings being used.)

Bearing lifetime

Prolonged storage periods reduce the useful lifetime of the bearing grease. For permanently lubricated bearings, this reduces the bearing service life.

We recommend that the grease is replaced after a storage time of 12 months. Replace greased bearings also in the case of closed bearings (uffic 22 or 2 RS). After 4 years in storage, generally replace all rolling bearings and grease.

Replacing bearings:

Replacement interval after which bearings are to be replaced under normal operating conditions:

Table 9-5: Bearing replacement intervals

Ambient temperature	Principle of operation	Bearing replacement intervals
-50 °C	Horizontal coupling operation	50,000 h
-50 °C	With axial and radial forces	20,000 h



- Do not reuse bearings that have been removed.
- Remove the dirty spent grease from the bearing shield.
- Replace the existing grease with new grease.
- Replace the shaft seals when the bearings are replaced.
- Slightly grease the contact surfaces of the sealing lip.

Note

Special operating conditions

The operating hours are reduced, e.g.:

- When motors are vertically mounted.
- High vibration and surge loads
- Frequent reversing operation
- Higher ambient temperatures.
- High speeds etc.



(1) Heat up 80 ... 100 °C

9.3.1.1 Bearing bushes

Protect the bearings against the ingress of dirt and moisture.

When fitting the bearing cartridges, observe the specified screw tightening torques (Page 119).

9.3.1.2 Installing bearings

Sealing the bearings

Note the following details:

- Shaft sealing rings are used to seal motion at the rotor shaft.
 - For V ribgt, comply with the assembly dimension.
- Use the specified bearings.
- Ensure that the bearing sealing disks are in the correct position.
- Insert the elements for bearing preloading at the correct end.
- Fixed bearings can have a locking ring or bearing cover.
- Seal the bearing cap screws with the appropriate gaskets or with grease.
- Do not interchange the position of the bearing covers (DE and NDE or inner and outer).


Danger as a result of rotor falling out

If the motor is in a vertical position, the rotor can fall out while work is being performed on the locating bearing. This can result in death, serious injury or damage.

- Support or unload the rotor when carrying out work with the motor in a vertical position.

Installing rolling bearings

- Extreme caution and attention to cleanliness are vital when installing rolling bearings. Observe the correct assembly sequence of the components.
- Attach all components with the specified tightening torques (Page 119).
- For individually mounted angular contact ball bearings, carefully comply with the installation position corresponding to the permissible direction of force.



- Angular contact ball bearings arranged in pairs must always be installed in strict compliance with the manufacturer's specifications.
- Always use angular contact ball bearings of the same type.

Note

For further information about mounting the rolling bearing, please refer to the catalog or the information provided by the rolling bearing manufacturer.

Procedure

1. Replace the damaged components.
2. Remove any dirt from the components. Remove any grease and the remains of sealant or liquid threadlocker.
3. Prepare the bearing seats:
 - Lightly oil the inner ring seat.
 - Grease the outer ring seat with a solid lubricant such as Altemp Q N8 52.
 - Press the inner bearing cover onto the shaft.
4. Warm up the rolling bearing.
5. Push the inner ring of the warmed up rolling bearing onto the shaft. Avoid any blows that might damage the bearing.
6. Ensure that the rolling bearing is seating against the shaft shoulder or the 2nd bearing.
7. Fill the bearing to the top with the specified lubricating grease as stamped on the lubricant plate.
8. Warm up the grease finger (if one is available), and push it onto the shaft.
9. Depending on the particular version, fix the bearing with a locking ring or shaft nut.
10. Support the motor when installing the bearing housing or bearing and shield.
11. Use a suitable sealant when assembling.
12. Assemble the bearing shield or bearing housing together with the bearing shaft.
13. Install the outer bearing cover (if one is available).
14. Install the sealing elements.

9.3.2 Mounting dimension "X"

Mounting dimension "X" of V rings

Shaft height		X mm
71	4.5 ± 0.5	Standard design  Special design 
80 ... 112	6 ± 0.8	
132 ... 160	7 ± 1	
180 ... 225	11 ± 1	
250 ... 315	13.5 ± 1.2	

- Exercise caution and attention to the correct positioning are vital during installation and assembly.
- Make sure the sealing surface is free of dirt and damage.
- Lightly grease the sealing lip.

9.3.3 Fan

NOTICE

Destruction of the fan

Material damage can occur by forcefully removing the fan from the shaft.

Take care not to damage the snapping mechanisms on fans that are equipped with these.

Plastic fan

- Correctly expose the breakout openings provided in the fan plate.
- Heat up the fan to a temperature of approximately 50° C around the area of the fan.
- Use a suitable tool to pull off the fan (puller).
- Locate the arms of the pulling tool in the breakout openings and slightly tension the pressure screw of the tool.
- For fans with snapping mechanisms, simultaneously release the two snap-in lugs of the fan from the annular shaft groove. Keep the snap-in lugs in this position.
- Uniformly withdraw the fan from the shaft by turning the pressure screw of the pulling tool.
- Do not apply any hammer blows to avoid damaging the rotor shaft, the fan and the bearings.
- Order the appropriate new parts if damaged.

Metal fan

- Shaft height 73...90: Release the M5 set screw so that the fan can rotate freely on the shaft.
- Shaft height 100...115: Remove the locking ring.
- Use a suitable tool to pull off the fan (puller).
- Locate the arms of the pulling tool in the openings in the fan in the vicinity of the fan.
- Alternatively, place the pulling tool at the outer edge of the fan plate.
- Uniformly withdraw the fan from the shaft by turning the pressure screws of the pulling tool.
- Do not apply any hammer blows to avoid damaging the rotor shaft, the fan and the bearings.
- Order the appropriate new parts if damaged.

Canopy**Canopies with spacer bolts or with screwed mounting brackets:**

Forcibly removing or separating can destroy the distance bolts, the collecting elements of the mounting bracket or the fan cover.

- Release the fixing screw on the outer surface of the canopy.
- Under no circumstances remove the spacer bolts or the mounting bracket – or forcibly separate them from one another or the cover.

Canopies with welded support brackets

- Release the fixing screws at the contact location (canopy foot - mounting rail) at the outer surface of the cover mesh.

9.3.4 Canopy, encoder under the canopy

- For screwed canopies, insert the fastening screws through the holes on the outer surface of the canopy. Tighten the fastening screws with a torque of 3 Nm $\pm$ 10 %.

9.3.5 Tightening torques

Note the information in Chapter "Tightening torques for screw and bolt connections" (Page 119).

9.3.6 Screw lock washers

Nuts or bolts that are mounted together with locking, resilient and/or force-distributing elements (e.g., safety plates, spring-lock washers, etc.) must be refitted together with identical, fully functional elements.

Locking and sealing elements must always be replaced!

9.3.7 Links

- Replace any corroded screws.
- Take care not to damage the insulation of live parts.
- Document the position of any rating and supplementary plates that have been removed.
- Avoid damaging the centering edges.

9.3.8 Reassembly: Miscellaneous information

- Position all rating and supplementary plates as in the original state.
- Where relevant, fix electric cables.
- Check the tightening torques of all screws, as well as those of screws that have not been released.

9.3.9 Optional add-on units

Note:

Further documents

Observe all of the other documents included with this motor.

You can find additional operating instructions [here](#)

Source: [Source & Variant Page 117](#)

Mounting a Brake

Table 7.6 Accepting standard bodies for TEF entities

Shaft height	Pole	Brake maker	Model	Brake size	Brake torque (Nm)	Tightening torque for the manual release lever (Nm)
21	2	EMCO	14,45E	8	8	2.8
	A...B	Wittig	WFS45E	6	5	
30	2	EMCO	14,45E	10	14	4.8
	A...B	Wittig	WFS45E	8	10	2.8
40	2	EMCO	14,45E	12	32	4.8
	A...B	Wittig	WFS45E	10	20	
100	2	EMCO	14,45E	18	60	12
	A...B	Wittig	WFS45E	12	40	4.8
152	A...B	Wittig	WFS45E	14	60	12
152	2...8	EMCO	14,45E	18	150	29
180	2...8	EMCO	14,45E	20	200	
180	2...8	EMCO	14,45E	23	315	
200	2...8	EMCO	14,45E	25	400	
225	2...8	EMCO	14,45E	25	400	40

9.3.10 O-ring seal

If O-ring seals are present, you should check that they are in perfect condition and that the O-ring seals are properly seated in the grooves between the components. Replace damaged O-ring seals.

Dying seeds can be present on the following components, for instance:

- Adapters, cups
- Entries, glands
- Bearing seals
- End shield seals
- Thermal box sealing

9.3.11 Encoder

Note

Further documents

Observe all the manufacturer's documentations provided with the inverter.

9.3.12: Grounding brush

- Ensure that the micro-switch, if available with grounding brush unit, is connected to the drive interlock.
- Check the wearing status of the grounding brush regularly and replace it if necessary.


Spare parts

10.1 Part lists


Part	Description	Part	Description
1.40	End shield	5.89	Self tapping screw
1.43	Shut sealing ring	5.90	Terminal clamp
1.44	Isolating cover DE, white	5.99	Spring lock washer
1.45	Cover ring	5.99	Box
1.49	Ball	5.99	Seal
1.58	Spring rivet	5.99	Terminal housing
1.60	Rolling bearing	5.99	Box
1.63	T-plug	5.99	Grove plug
1.65	Grove nipple	6.02	Locking ring
1.70	Shim	6.03	ACE bearing cover, inner / for 260 ... 315
1.38	Fastener key	6.10	Rolling bearing
4.08	Epoxy (SH 785 ... 315)	6.20	End shield
4.31	Grounding bracket	6.23	Shut sealing ring
4.37	Ground terminal plate	6.25	Lubrication sleeve
4.38	Spring lock washer	6.29	Self tapping screw
4.39	Grounding stud	6.45	Grove nipple
4.40	Washer	7.00	Seal
5.05	Seal	7.40	Fan cover
5.10	Complete terminal board	7.89	Box
5.16	Self tapping screw		
5.21	Screw (drilled)		
5.36	Isolating bonding plate for cable bonding		
5.44	Upper section of the terminal box		

Tools for assembling and withdrawing rolling bearings, fan and output distribution elements cannot be supplied.

Shaft height 100...132



: Shaft height, 100—200



Disposal

Protecting the environment and preserving its resources are corporate goals of the highest priority for us. Our worldwide environmental management system to ISO 14001 ensures compliance with legislation and sets high standards in this regard. Environmentally friendly design, technical safety and health protection are always firm goals even at the product development stage.

Recommendations for the environmentally friendly disposal of the motor and its components are given in the following section. Be sure to comply with local disposal regulations.

Country-specific legislation



The motor uses materials that can be recovered or recycled. Correctly separating materials helps to simply recycle important materials.

- When disposing of the motor or of waste that is created during the individual phases of its life cycle, please observe the statutory requirements applicable in the country of use.
- Please contact your local authorities for more information about disposal.

11.1 RoHS - restricting the use of certain hazardous substances

In compliance with RoHS ("Restriction of certain Hazardous Substances") we replace substances that are damaging to the environment by those that are not based on state-of-the-art technology. In doing so, safety in operation and handling will take priority at all times.

This product contains one or several subproducts in which the following substance – belonging to the “list of candidates” – exists in a concentration exceeding 0.1 percent by weight:

- Based on the currently available information, we assume that this substance does not represent any risk when correctly used, including its disposal.

Quantities of the motor must be carried out and/or supervised by qualified personnel with appropriate expert knowledge.

- Disassemble the motor using the general procedures commonly used in mechanical engineering.



The motor is made up of heavy parts. These parts are liable to fall during dismantling. This can result in death, serious injury or material damage.

- Copyright Clearance Center, INC. 04-0012-1000 LIBRARY USE

Components

Sort the components for recycling according to whether they are:

- The windward insulation is increased during colder weather.

Sort the process materials and chemicals for recycling according to whether they are for multiple:

- Dispose of the separated components according to local regulations or via a specialist disposal company. The same applies for cloths and cleaning substances which have been used while working on the motor.

- If necessary, contact a suitable specialist disposal company.
- Wooden packaging for sea transport consists of impregnated wood. Observe the local regulations.
- The foil used for water-proof packaging is an aluminium compatible foil. It can be recycled thermally. Only foil must be disposed of via waste incineration.

Contact person:



If you wish to request on-site service or order spare parts, please contact your local office. This office will contact the responsible service center on your behalf. You can find your contact person in the relevant contact database:

<http://www.siemens.com/yourcontact> (<http://www.siemens.com/yourcontact>)

Siemens Support for on the move



With the "Siemens Industry Online Support" App, you can access more than 300,000 documents for Siemens Industry products – any time and anywhere. The App supports you in the following areas:

- Resolving problems when executing a project
- Troubleshooting when faults develop
- Expanding a system or planning a new system

Further, you have access to the Technical Forum and other articles that our experts have drawn up:

- FAQs
- Application examples
- Manuals
- Certificates
- Product announcements and many more

The app is available for Apple iOS, Android and Windows Phone.

A.3 Further documents

These operating instructions can also be obtained at the following internet site:

<http://support.industry.siemens.com> (Page 117)

B.2 Tightening torques

Tightening torques

The bolted connections with metal contact surfaces, such as end shields, bearing cartridge parts, terminal box parts bolted onto the stator frame, should be tightened to the following torques, depending on the thread size:

Table B-1 Tightening torques for bolted connections with a tolerance of $\pm 10\%$

Thread Ø	M4	M6	M8	M10	M12	M16	M20	M24
Nm	5	8	20	40	70	170	360	600

The tightening torques stated above apply to screws with property class 8.8, A4-70 or A4-80 according to ISO 898-1, however only to bolts screwed into components made from materials with the same or higher property class, e.g. cast iron, steel or cast steel.

Non-standard tightening torques

Different tightening torques for electrical connections and bolted connections for parts with flat seals or insulating parts are specified in the relevant sections and drawings.

B.2.2 Terminal board and grounding

Table B-2 Tightening torques for electrical connections on the terminal board and grounding

Thread Ø		M 3.5	M 4	M 5	M 6	M 8	M 10	M 12	M 16
Nm	min	0.8	0.8	1.8	2.7	5.5	9	16	27
	max	1.2	1.1	3.5	5	8	18	20	45

B.2.3 Terminal boxes, end shields, grounding conductors, sheet metal fan covers

If no other tightening torques are specified, then the values in the following table apply:

Table B-3 Tightening torques for screws on the terminal box, end shields, screw-type grounding conductor connections

Thread Ø		M 3.5	M 4	M 5	M 6	M 8	M 10	M 12	M 16	M 20
Nm	min	0.8	1	3.5	6	10	20	40	110	225
	max	1.2	3	5	9	24	42	70	160	340

Table B-4 Tightening torques for self-tapping screws on the terminal box, end shields, screw-type grounding conductor connections, sheet metal fan covers

	Thread Ø		M 4	M 5	M 6
	Nm	min	4	7,5	12,5
		max	5	9,5	15,5

B.2.4 Tightening torques for electrical connections of monitoring equipment and anti-condensation heating

Table B.5 Tightening torques for monitoring equipment and anti-condensation heating

Main terminal box EN 60999-1: 2000 type 4 or	2.4 Nm	
Auxiliary terminal box	min 0.8 Nm	max 0.8 Nm

B.2.5 Tightening torques for cable glands

Note

Avoid damaging the cable jacket.

Adapt the tightening torques to the cable jacket materials.


You should refer to the table in order to find the correct tightening torque for any metal and plastic cable glands that are to be mounted directly on the motor, as well as for any other screw-type connections (such as adapters).

Table B.6 Tightening torques for cable glands

	Metal ± 10 % Nm	Plastic ± 10 % Nm	Clamping range [mm]	O-ring O-ring dia. mm
			Standard -35 °C ... 100 °C	
M 12 x 1.5	8	5.5	5.0 ... 7.5	2
M 16 x 1.5	10	7	7.5 ... 10.0	
M 20 x 1.5	12	8	10.0 ... 12.5	
M 25 x 1.5			12.5 ... 15.0	
M 32 x 1.5	18	6	15.0 ... 21.0	
M 40 x 1.5			19.0 ... 25.0	
M 50 x 1.5	20		24.0 ... 31.0	
M 63 x 1.5			34.0 ... 45.0	

B.3 Technical data and drawings

B.3.1 Terminal box dimensions




Shaft height	Terminal box	A	B	C	D	E	F	G	H	I	Cable entry
75 ... 90	TB7 F04	89	111	23	47,3	62,7	33,5	32,5	M4		1 x M16 x 1,5 1 x M25 x 1,5
100 ... 112	TB7 F04	126	163	48	80,5	92,5	33	33	M5		2 x M32 x 1,5
132	TB1 F04	134	163	48	80	83	48	48	M5		2 x M32 x 1,5
160 ... 180	TB1 F04	165	190	60	92	98	66	66	M5		2 x M40 x 1,5
200	TB1 L01	197	266	85	112	151	68	68	M6		2 x M50 x 1,5
225	TB1 L01	197	266	85	112	151	68	68	M6		2 x M50 x 1,5
250 ... 280	TB1 F03	233	319	110	145	174	79	79	M10		2 x M63 x 1,5
315	TB1 Q01	299	374	110	168	210	106	106	M12		2 x M63 x 1,5

Note

The dimensions stated above apply to the standard execution. For detailed information about the terminal box, refer to the Order Document respectively.

B.3.2 Arrangement of the auxiliary terminal box



Quality documents

C.1 Quality documents SIMOTICS in SIOS



You can find the quality documents here:

<https://support.industry.siemens.com/cs/ww/en/ps/13310/cert>
(<https://support.industry.siemens.com/cs/ww/en/ps/13310/cert>)

Index

4

Siemens Industry Online Support App 118

5

5 safety rules 11

A

Aligning 32, 33
 Aluminum conductors 68
 Anti-condensation heating 36
 Insulation resistance 44
 Assembly
 Rolling bearing 100
 Axial force 53
 Axial gap 51

B

Balancing type 54
 Bearing currents
 Reduction 40
 Bearing insulation 41
 Bearing shipping brace 33
 Bearing temperature
 Monitoring 74
 Set values 78
 Blocked speed ranges 37
 Bolt locking device 119

C

Centering flange 32, 33
 Circuit diagram 63
 Connecting cables
 Selection 59
 Contact 113
 Cooling system
 Faults 68
 Correct usage 18
 Coupling 42

D

Disassembly
 Disposal 114
 Disposal
 Chemicals 115
 Components 115
 Drive output element 35

E

Electrical faults 56
 Electromagnetic compatibility 16
 Electromagnetic fields 14
 Emergency off 63
 Emitted interference 14
 Equipotential bonding conductor 40
 ESD guidelines 14
 External fan
 Commissioning 75
 Maintenance 87
 Test run 75

F

Faults
 Cooling system 68
 Electric 66
 Inspection 66, 61
 Mechanical 67
 Rolling bearings 67
 Faults in operation 60
 Flaring 58
 Flammable substances 13
 Foundation forces 31
 Frequency fluctuation 37

G

General inspection 62
 Grounding system
 Washed 41

H

Hazardous substances	13
Hearing damage	13
Hot surfaces	13

I

Inspection	
Faults	86, 91
Installation	
Initial inspection	91
Insulated bearings	41
Insulated coupling	42
Insulation resistance	33, 43, 74, 96
Anti-condensation heating	46
Measure	46
Interference immunity	13
Interlocking circuit	
Anti-condensation heating	36
Separately driven fan	38

L

Limit speed	39
Live parts	12
Low-voltage Directive	11

M

Maintenance	
Maintenance intervals	89
Mechanical faults	87
Minimum air clearances	62
Motor	
Aligning to the driven machine	31
Securing	51
Motor expansion	52

N

Noise emissions	13
-----------------------	----

O

On-site service	118
Operating mode	25
O-ring seals	105
Over-critical motor	37
Overspeed	26

P

Pallet system	89
Paintwork damage	89
Polarization index	33, 43, 74, 96
Positioning	31
Precision alignment	31
Preload	
Rotor bracing	32
Preparations for assembly	44
Property class	31

Q

Qualified personnel	12
---------------------------	----

R

Radial force	55
Rating plate	18
REACH regulation	114
Re-commissioning	85
Regreasing system	33
Repair	
Initial inspection	91
Residual risks	26
Restriction of certain Hazardous Substances	113
RF grounding point	40
Risk of explosion	17
Rorts	113
Rolling bearings	
Assembly	100
Faults	87
Inspection	92
Rotating parts	12
Rotor chipping brace	31
Remove	53

S

Safety instructions	
Flammable substances	13
Hazardous substances	13
Hot surfaces	13
Live parts	12
Rotating parts	12
Selection of bolts	31
Separately driven fan	38
Siemens Industry Online Support	
App	118
Spare parts	118

Standard flange	52, 53
Stoppages	84
Rolling bearings	85
Supplementary devices	13
Switching on	78, 79, 85
System resonances	37

T

Tandem operation	42
Technical Support	117
Terminal marking	61
Test run	78
Tightening torques	58
Bolted connection	110

V

Vibration values	37, 78
Voltage fluctuations	37

W

Water drip loop	37
-----------------------	----

For more information [visit here](https://www.siemens.com) or call us on 1800 500 1800

For the Cycle Support of Products, Systems and Services call us on 1800 206 0007



Siemens Limited
Digital Industries
Motion Center
880 Technology Centre
Thane Bypass Road
Airoli Estate
Mumbai - 400 708

Disclaimer:
Subject to change and error. The information given in this document only serves general design guidance and is not a performance feature which may not always especially reflect these features, or which may undergo modification in the course of further development of the product. The registered performance values exclusively apply when they are explicitly agreed upon in the contract. An explicit disclaimer may be necessary to take rights of Siemens AG, its affiliated companies and companies associated with them (hereinafter referred to as "Siemens") out of the scope of the legal provisions.